

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	A43	A/C Amplifier	90980-11502
A 2	A/C Condenser Fan Motor	90980-11237	A44	A/C Amplifier	90980-10801
A 4	Pressure SW (w/ Rear A/C)	90980-10943	A45	ABS Speed Sensor Rear LH (Independent Suspension)	90980-11073
	Pressure SW (w/o Rear A/C)	90980-11149		ABS Speed Sensor Rear LH (Rigid Axle Suspension)	90980-11075
A 5	A/C Magnetic Clutch	90980-11271	A46	ABS Speed Sensor Rear RH (Independent Suspension)	90980-11073
A 6	A/C Magnetic Clutch and Lock Sensor	90980-11016		ABS Speed Sensor Rear RH (Rigid Axle Suspension)	90980-11075
A 7	A/C Magnetic Valve	90980-11075	A47	Accumulator Solenoid	90980-11019
A 9	A/T Oil Temp. Sensor	90980-11243	A48	ABS & BA & TRC & VSC Actuator	90980-11413
A10	ABS Actuator	90980-11413	A49	ABS & BA & TRC & VSC Actuator	90980-10895
A11	ABS Actuator	90980-10895	A50	ABS & BA & TRC & VSC Actuator	90980-11151
A12	ABS Actuator	90980-11151	A51	ABS & BA & TRC & VSC Actuator	90980-11009
A13	ABS Actuator	90980-11009	A52	ABS & BA & TRC & VSC ECU	90980-11935
A15	ABS Speed Sensor Front LH	90980-10941	A53	ABS & BA & TRC & VSC ECU	90980-11476
A16	ABS Speed Sensor Front RH	90980-11002	A54	ABS & BA & TRC & VSC ECU	90980-11637
A17	Accel Position Sensor (1HD-FTE)	90980-11232	A55	ABS & BA & TRC & VSC ECU	90980-11638
	Accel Position Sensor (2UZ-FE)	90980-11144	A56	ADD Control Motor	90980-11024
A18	AHC Pump Motor	90980-10928	A57	A/C Control Assembly	90980-12170
A19	Air Cleaner Warning Sensor	90980-11025	A58	A/C Control Assembly	90980-11913
A20	Air Flow Meter	90980-11317	A59	A/C Control Assembly	90980-11927
A21	Airbag Sensor Front LH	90980-11856	A60	A/T Shift Lever Illumination	90980-11911
A22	Airbag Sensor Front RH		Shift Lock Control ECU		
A23	Alternator (1HD-FTE, 1HZ)	90980-09372	A61	ADD Control Relay	90980-10801
	Alternator (2UZ-FE, 1FZ-FE)	90980-09212	A62	Airbag Sensor Assembly (w/ Side Airbag)	82824-50150
A24	Alternator (1FZ-FE, 1HD-FTE, 1HZ)	90980-11349		Airbag Sensor Assembly (w/o Side Airbag)	90980-11871
	Alternator (2UZ-FE)	90980-11964	A63	Airbag Sensor Assembly (w/ Side Airbag)	82824-50160
A25	Auto Antenna Motor	90980-11194		Airbag Sensor Assembly (w/o Side Airbag)	90980-11873
A26	A/C Solar Sensor	90980-11919	A64	Auto Wiper ECU	90980-10801
A27	A/C Thermistor	90980-11918		Short Connector	
A28	ABS Deceleration Sensor	90980-10845	A65	Auto Wiper ECU	90980-12183
A29	ABS ECU	90980-11424	A66	Automatic Light Control Sensor	90980-12056
A30	ABS ECU	90980-11391	A67	Airbag Sensor Assembly	90980-11872
A31	ABS ECU	90980-11390	A68	A/T Shift Lever Illumination	90980-11614
A32	Accelerator Pedal SW	90980-10825		O/D Main SW	
A33	AHC Main Relay	90980-10171		Shift Lock Control ECU	
A34	Air Inlet Control Servo Motor	90980-11909	B 1	Back-Up Light SW (Except 1HZ)	90980-11051
A35	Air Mix Control Servo Motor (LHD)	90980-10797		Back-Up Light SW (1HZ)	90980-11250
	Air Mix Control Servo Motor (RHD)	90980-11529	B 2	Brake Fluid Level Warning SW	90980-11207
A36	Air Vent Mode Control Servo Motor (LHD)	90980-11165	B 3	Blower Motor Controller (LHD, RHD Europe)	90980-10910
	Air Vent Mode Control Servo Motor (RHD)	90980-11321		Blower Motor Controller (RHD Except Europe)	90980-11667
A37	Airbag Squib (Front Passenger Airbag Assembly)	90980-12160	B 4	Blower HI Relay	90980-10713
A38	Airbag Squib (Steering Wheel Pad)				
A39	Ashtray Illumination	90980-10825			
A40	Auto Antenna Control Relay	90980-10819			
A41	A/C Amplifier	90980-11497			
A42	A/C Amplifier	90980-11475			

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
B 5	Blower LO Relay	90980-10171	D 3	Detection SW (Transfer Neutral Position)	90980-11025
B 6	Blower ME Relay		D 4	Diesel Engine Revolution Sensor	90980-11250
B 7	Back Door Courtesy SW (Liftgate Type)	90980-10039	D 5	Damping Mode Select SW and Height Control SW	90980-11923
	Back Door Courtesy SW (Swing Type)	90980-11367	D 7	Diode (Front Fog No.1)	90980-10637
B 8	Back Door Key Lock and Unlock SW (Liftgate Type)	90980-11490	D 8	DLC3	90980-11665
	Back Door Key Lock and Unlock SW (Swing Type)	90980-11169	D 9	Door Lock Control SW (LHD)	90980-10797
B 9	Back Door Lock Motor and Back Door Unlock Detection SW	90980-11150		Door Lock Control SW (RHD)	90980-10996
B10	Buckle SW LH	90980-11169	D10	Damping Force Control Actuator Front LH	90980-11960
B11	Buckle SW RH		D11	Damping Force Control Actuator Front RH	
B12	Body ECU		90980-12151	D12	
B13	Body ECU	90980-12149	D13	Damping Force Control Actuator Rear RH	
B14	Body ECU	90980-12150	D14	Detection SW (Rear Diff. Lock) (Independent Suspension)	90980-11156
B15	Buckle SW LH	90980-11599		Detection SW (Rear Diff. Lock) (Rigid Axle Suspension)	90980-11250
	Seat Position Sensor		D15	Door Courtesy Light Front LH	90980-11148
B16	Buckle SW RH		D16	Door Courtesy Light Front RH	
	Seat Position Sensor		D17	Door Courtesy Light Rear LH	
C 1	Camshaft Position Sensor	90980-10947	D18	Door Courtesy Light Rear RH	
C 2	Center Diff. Lock Control Motor	90980-11024	D19	Door Courtesy SW Front LH	
C 3	Check Connector	90980-11195	D20	Door Courtesy SW Front RH	
C 4	Crankshaft Position Sensor (1FZ-FE)	90980-11016	D21	Door Courtesy SW Rear LH	
	Crankshaft Position Sensor (1HD-FTE)	90980-11162	D22	Door Courtesy SW Rear RH	
	Crankshaft Position Sensor (2UZ-FE)		D23	Door Key Lock and Unlock SW LH	90980-11170
C 6	CD Automatic Changer (LHD)	90980-10803	D24	Door Key Lock and Unlock SW RH	
	CD Automatic Changer (RHD)	90980-12200	D25	Door Lock Motor Front LH	90980-11150
C 8	Center Diff. Lock Control Relay	90980-10801		Door Unlock Detection SW Front LH	
C13	Cigarette Lighter	90980-10760	D26	Door Lock Motor Front RH	
C14	Cigarette Lighter Illumination	90980-11148		Door Unlock Detection SW Front RH	
C15	Combination Meter	82824-60060	D27	Door Lock Motor Rear LH	
C16	Combination Meter	82824-60050		Door Unlock Detection SW Rear LH	
C17	Combination Meter	82824-60060	D28	Door Lock Motor Rear RH	
C18	Combination Meter	82824-60050		Door Unlock Detection SW Rear RH	
C19	Combination SW (LHD, RHD Europe)	90980-11672	D29	Driving Position Memory SW	90980-10601
	Combination SW (RHD Except Europe)	90980-11671	D30	Detection SW (Front Diff. Lock)	90980-11250
C20	Combination SW	90980-12155	D32	Diesel Throttle Position SW	90980-11038
C22	Combination SW	90980-11594	D33	Deceleration Sensor	90980-12080
C23	Cooler Box	90980-11535	D34	Diode (Front Fog No.2)	90980-10637
C24	Cruise Control Clutch SW	90980-10906		D35	
C26	Control Valve Assembly	90980-11599	D36	Diode (Viscous Heater2)	
C32	Center Cluster Integration Panel	90980-12200	D37	Double Lock Control Relay	90980-10807
C33	Combination SW	90980-12183	D38	Door Control Receiver	90980-11909
C35	Curtain Shield Airbag Squib LH	90980-11864			
C36	Curtain Shield Airbag Squib RH				
D 1	Detection SW (Center Diff. Lock)	90980-11250			
D 2	Detection SW (Transfer L Position)				

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number	
D39	Door Lock Motor Front LH	90980-10890	E19	Engine and ECT ECU	90980-12142	
	Door Unlock Detection SW Front LH			Engine ECU		
	Double Lock Motor Front LH		E20	Engine and ECT ECU	90980-11129	
	Double Lock Position SW Front LH			Engine ECU		
D40	Door Lock Motor Front RH		E21	Emission Control ECU	90980-11390	
	Door Unlock Detection SW Front RH			E22	Emission Control ECU	90980-11391
	Double Lock Motor Front RH		F 1	First Position SW	90980-10923	
	Double Lock Position SW Front RH		F 2	Fluid Pressure Sensor	90980-11451	
D41	Door Lock Motor Rear LH		90980-10891	F 3	Front Clearance Light LH	90980-11156
	Door Unlock Detection SW Rear LH			F 4	Front Clearance Light RH	
	Double Lock Motor Rear LH			F 5	Front Fog Light LH	90980-11660
	Double Lock Position SW Rear LH			F 6	Front Fog Light RH	
D42	Door Lock Motor Rear RH			F 7	Front Side Turn Signal Light LH	90980-11162
	Door Unlock Detection SW Rear RH			F 8	Front Side Turn Signal Light RH	
	Double Lock Motor Rear RH			F 9	Front Turn Signal Light LH	90980-11019
	Double Lock Position SW Rear RH			F10	Front Turn Signal Light RH	
E 1	ECT Solenoid (1FZ-FE)	90980-10854		F11	Front Wiper Motor	90980-11599
	ECT Solenoid (2UZ-FE, 1HD-FTE)	90980-12293		F12	Fuel Cut Valve Controller	90980-11349
E 2	EFI Water Temp. Sensor (1FZ-FE, 1HD-FTE)	90980-10737		F13	Fuel Heater SW	90980-10928
	EFI Water Temp. Sensor (2UZ-FE)	90980-10736		F14	Fuel Pump Resistor	90980-11156
E 3	Engine Hood Courtesy SW	90980-11003		F15	Fuel Sediment SW	90980-11003
E 6	ECT Pattern Select SW	90980-10933		F16	Fuel Temp. Sensor	90980-10737
E 7	Engine and ECT ECU	90980-12144		F17	Fusible Link Block	82675-60050
	Engine ECU			F19	Front Blower Motor	90980-10903
E 8	Engine and ECT ECU	90980-12145	F20	Front Blower Resistor (LHD)	90980-10910	
	Engine ECU			Front Blower Resistor (RHD)	90980-11136	
E 9	Engine and ECT ECU	90980-12143	F21	Front/Rear Diff. Lock Control SW	90980-10631	
	Engine ECU		F22	Fuel Tank Changeover SW	90980-10933	
E10	Engine and ECT ECU	90980-12146	F23	Front Door Speaker LH	90980-10935	
	Engine ECU		F24	Front Door Speaker RH		
E11	Engine and ECT ECU	90980-12142	F25	Front Interior Light		
	Engine ECU		F26	Front Personal Light	90980-10825	
E12	Engine and ECT ECU	90980-11391	F27	Front/Rear Diff. Lock Control ECU	90980-10848	
	Engine ECU		F28	Fuel Pump	90980-11077	
E13	Engine and ECT ECU	90980-11390		Fuel Sender		
	Engine ECU		F30	Fuel Pump Select Relay	90980-10173	
E14	Engine and ECT ECU	90980-11392	F31	Fuel Solenoid Valve 1	90980-10901	
	Engine ECU		F32	Fuel Solenoid Valve 2		
E15	EDU	90980-11024	F33	Front Diff. Lock Motor	90980-11290	
E16	Engine and ECT ECU	90980-12144	F35	Fuel Pump Resistor LH	90980-11156	
	Engine ECU		F36	Fuel Pump Resistor RH		
E17	Engine and ECT ECU	90980-12145	F37	Fusible Link Block	90980-11996	
	Engine ECU		F38	Fusible Link Block	90980-11881	
E18	Engine and ECT ECU	90980-12146	F39	Fusible Link Block	90980-11775	
	Engine ECU		F40	Fusible Link Block	90980-10995	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number	
G 1	Glow Plug	99141-13004	I16	Injector No.7	90980-11153	
G 2	Glow Plug Relay	90980-11569	I17	Injector No.8		
G 3	Glove Box Light	90980-11098	I18	Intake Air Temp. Sensor (1FZ-FE)	90980-11163	
G 4	Gateway ECU	90980-11911		Intake Air Temp. Sensor (1HD-FTE)	90980-11025	
H 1	Headlight Beam Level Control Actuator LH	90980-11016	I19	Intake Heater	99141-14006	
H 2	Headlight Beam Level Control Actuator RH					
H 3	Headlight Cleaner Control Relay	90980-10939	I20	Intake Heater Relay	90980-11248	
H 4	Headlight Cleaner Motor	90980-11410	I21	Intake Heater Relay	99141-14006	
H 5	Headlight Control ECU LH	90980-11255	I22	Intake Heater Relay		
H 6	Headlight Control ECU RH					
H 7	Headlight LH (High)	90980-11659	I23	ISC Valve	90980-11145	
H 8	Headlight RH (High)					
H 9	Headlight LH (Low)	90980-11660	I24	Idle-Up SW	90980-10933	
H10	Headlight RH (Low)					
H11	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-10869	I26	Ignition SW	90980-11615	
H12	Heated Oxygen Sensor (Bank 1 Sensor 2)	90980-11028	I30	Inner Mirror	90980-11186	
H13	Heated Oxygen Sensor (Bank 2 Sensor 1)	90980-10869	J 1	Junction Connector	90980-11915	
H14	Heated Oxygen Sensor (Bank 2 Sensor 2)	90980-11028	J 2	Junction Connector		
H15	Height Control Sensor Front LH	90980-11015	J 3	Junction Connector		
H16	Height Control Sensor Front RH					
H17	Horn LH	90980-10619	J 4	Junction Connector	90980-11398	
H18	Horn RH					
H19	Headlight Beam Level Control SW	90980-10996	J 5	Junction Connector		
H20	Height Control Sensor Rear	90980-11143	J 6	Junction Connector		90980-11927
H21	High Mounted Stop Light (Liftgate Type)	90980-11211	J 7	Junction Connector	90980-11661	
	High Mounted Stop Light (Swing Type)	90980-10825	J 8	Junction Connector		
H22	Heated Oxygen Sensor	90980-11028	J 9	Junction Connector		
H23	Headlight Cleaner SW	90980-12063	J10	Junction Connector		90980-10803
I 1	Ignition Coil and Igniter No.1 (1FZ-FE)	90980-11150	J11	Junction Connector		
	Ignition Coil and Igniter No.1 (2UZ-FE)	90980-11885	J12	Junction Connector		
I 2	Ignition Coil and Igniter No.2 (1FZ-FE)	90980-11150	J13	Junction Connector	90980-11398	
	Ignition Coil and Igniter No.2 (2UZ-FE)	90980-11885	J14	Junction Connector		
I 3	Ignition Coil and Igniter No.3 (1FZ-FE)	90980-11150	J15	Junction Connector		
	Ignition Coil and Igniter No.3 (2UZ-FE)	90980-11885	J16	Junction Connector		90980-11927
I 4	Ignition Coil and Igniter No.4	90980-11885	J17	Junction Connector		
I 5	Ignition Coil and Igniter No.5		J19	Junction Connector		
I 6	Ignition Coil and Igniter No.6		J21	Junction Connector	90980-11742	
I 7	Ignition Coil and Igniter No.7		J22	Junction Connector		
I 8	Ignition Coil and Igniter No.8		J24	Junction Connector	90980-11925	
I 9	Injection Pump		90980-11028	J25		Junction Connector
I10	Injector No.1		90980-11153	J26		Junction Connector
I11	Injector No.2			J27		Junction Connector
I12	Injector No.3	J28		Junction Connector	90980-11925	
I13	Injector No.4	J29		Junction Connector		
I14	Injector No.5	J30		Junction Connector	90980-11166	
I15	Injector No.6	J31		Junction Connector		
			J32	Junction Connector		
			J33	Junction Connector		
			J34	Junction Connector		
			J35	Junction Connector		
			K 1	Knock Sensor (Bank 1)	90980-11166	
			K 2	Knock Sensor (Bank 2)		

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
K 3	Key Interlock Solenoid	90980-10825	P23	Power Seat Control SW (Driver's Seat)	90980-10803
L 1	License Plate Light	90980-11159	P24	Power Seat Control SW (Front Passenger's Seat)	
L 2	License Plate Light LH	90980-11148	P27	Power Seat Motor (Driver's Seat Front Vertical Control)	90980-10825
L 3	License Plate Light RH				
L 4	Lumbar Support Control SW (Driver's Seat)	90980-10601	P28	Power Seat Motor (Driver's Seat Lumbar Support Control)	
L 5	License Plate Light No.1	90980-11159	P29	Power Seat Motor (Driver's Seat Rear Vertical Control)	
L 6	License Plate Light No.2	90980-10871	P30	Power Seat Motor (Driver's Seat Reclining Control)	
M 1	Moon Roof Control ECU	90980-10997	P31	Power Seat Motor (Driver's Seat Slide Control)	
M 2	Moon Roof Control SW	90980-10789	P32	Power Seat Motor (Front Passenger's Seat Front Vertical Control)	
M 3	Master Cylinder Pressure Sensor	90980-11451	P33	Power Seat Motor (Front Passenger's Seat Rear Vertical Control)	
M 4	Multi-Display (w/ Navigation System)	90980-12203	P34	Power Seat Motor (Front Passenger's Seat Reclining Control)	
	Multi-Display (w/o Navigation System)	90980-12094	P35	Power Seat Motor (Front Passenger's Seat Slide Control)	
M 5	Multi-Display	90980-12410	R 2	Radio and Player	90980-10997
N 1	A/T Indicator Light SW (1FZ-FE)	90980-11332	R 3	Radio and Player	90980-10803
	A/T Indicator Light SW (2UZ-FE, 1HD-FTE)	90980-11784	R 4	Radio and Player	90980-10996
	Neutral Start SW (1FZ-FE)	90980-11332	R 6	Rear Diff. Lock Control ECU	90980-10801
	Neutral Start SW (2UZ-FE, 1HD-FTE)	90980-11784	R 7	Rear Fog Light SW	90980-12113
N 2	Noise Filter (Ignition)	90980-10843	R 9	Remote Control Mirror SW	90980-11657
N 4	Navigation ECU	90980-11973	R10	Remote Control Mirror SW	90980-11319
N 5	Navigation ECU	90980-11923	R11	Rheostat (Except Optitron Meter)	90980-10908
N 6	Noise Filter (ABS)	90980-10983		Rheostat (Optitron Meter)	90980-10799
N 7	Navigation ECU	90980-12221	R12	Room Temp. Sensor (Front)	90980-11918
O 3	Oil Level Sensor (1FZ-FE)	90980-11235	R13	Rear A/C Control SW (Rear Automatic A/C)	90980-11503
	Oil Level Sensor (1HD-FTE, 1HZ)	90980-10532		Rear A/C Control SW (Rear Manual A/C)	90980-10878
	Oil Level Sensor (2UZ-FE)				
O 4	Oil Pressure Sender (1HD-FTE, 1HZ)	90980-10703	R14	Rear Air Mix Control Servo Motor	90980-11319
	Oil Pressure Sender (2UZ-FE, 1FZ-FE)	90980-11363	R15	Rear Combination Light LH	90980-11587
O 5	Overhead J/B	90980-11909	R16	Rear Combination Light LH (w/ Rear Fog Light)	90980-10825
O 6	Overhead J/B	90980-12155		Rear Combination Light LH (w/o Rear Fog Light)	90980-10908
P 1	Pick-Up Sensor	90980-11157	R17	Rear Combination Light RH	90980-11587
P 2	Power Steering Oil Pressure SW	90980-11428	R18	Rear Combination Light RH (w/ Rear Fog Light)	90980-10825
P 3	Power Outlet (Front)	90980-10760		Rear Combination Light RH (w/o Rear Fog Light)	90980-10908
P 6	Pre-Heating Timer	90980-10803	R19	Rear Cooler Blower Motor	90980-10214
P 7	Parking Brake SW	90980-10871	R20	Rear Cooler Magnetic Valve	90980-10860
P 8	Power Outlet (Luggage Compartment)	90980-10860	R21	Rear Cooler Power Transistor	90980-10171
P11	Power Window Control SW Front LH	90980-11947		R22	
	Power Window Control SW Front RH				
P13	Power Window Control SW Rear LH		R23	Rear Diff. Lock Motor (Independent Suspension)	90980-11194
P14	Power Window Control SW Rear RH			Rear Diff. Lock Motor (Rigid Axle Suspension)	90980-11290
P15	Power Window Master SW	90980-12166			
P17	Power Window Motor Front LH	90980-11599			
P18	Power Window Motor Front RH				
P19	Power Window Motor Rear LH				
P20	Power Window Motor Rear RH				
P21	Pretensioner LH	90980-11862			
P22	Pretensioner RH				

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number	
R24	Rear Door Speaker LH	90980-10935	S 7	Suspension Control ECU	90980-11424	
R25	Rear Door Speaker RH		S 8	Suspension Control ECU	90980-11391	
R26	Rear Evaporator Temp. Sensor	90980-11918	S 9	Suspension Control ECU	90980-11390	
R27	Rear Heater Blower Motor	90980-10860	S10	Seat Heater SW (Driver's Seat) (LHD)	90980-10797	
R28	Rear Heater Blower Resistor	90980-10916		Seat Heater SW (Driver's Seat) (RHD)	90980-10996	
R29	Rear Heater Control SW	90980-10797	S11	Seat Heater SW (Front Passenger's Seat) (LHD)	90980-10996	
R30	Rear Heater Power Transistor	90980-10171		Seat Heater SW (Front Passenger's Seat) (RHD)	90980-10797	
R31	Rear Heater Relay		S14	Sub Fuel Pump	90980-11038	
R32	Rear Inlet Air Temp. Sensor	90980-11369	S15	Sub Fuel Pump Forcing Driving Relay	90980-10171	
R33	Rear Interior Light	90980-10935	S16	Sub Fuel Sender	90980-11016	
R34	Rear Personal Light (w/ Moon Roof)	90980-12211	S17	Seat Belt Warning Occupant Detection Sensor	90980-10860	
	Rear Personal Light (w/o Moon Roof)	90980-10365				
R35	Rear Window Defogger	90980-11097	S18	Seat Heater (Driver's Seat)	90980-10907	
R36	Rear Window Defogger					
R37	Rear Window Defogger LH	90980-10792	S19	Seat Heater (Front Passenger's Seat)	90980-11156	
R38	Rear Window Defogger LH					
R39	Rear Window Defogger RH					
R40	Rear Window Defogger RH					
R41	Rear Wiper Motor	90980-10795	S21	Side Airbag Sensor Front LH	90980-12225	
R42	Rear Wiper Motor LH					
R43	Rear Wiper Motor RH					
R44	Rear Wiper Relay (Liftgate Type)		90980-10797	S22		Side Airbag Sensor Front RH
	Rear Wiper Relay (Swing Type)	90980-10801	S23	Side Airbag Sensor Rear LH		
R47	Remote Control Mirror ECU	90980-11877	S24	Side Airbag Sensor Rear RH	90980-11877	
R48	Remote Control Mirror LH	90980-11573	S25	Stereo Component Amplifier		
R49	Remote Control Mirror RH		S26	Stereo Component Amplifier	90980-11877	
R50	Room Temp. Sensor (Rear)	90980-11918	S27	Seat Heater (Driver's Seat Cushion)	90980-10794	
R53	Radio and Player	90980-12038	S28	Seat Heater (Front Passenger's Seat Cushion)		
R54	Radio and Player	90980-12259	S29	Seat Position Sensor	90980-12195	
R55	Radio and Player	90980-12183	S30	Side Airbag Squib LH	90980-11864	
R56	Rear Diff. Lock Control SW	90980-10631	S31	Side Airbag Squib RH		
R57	Rear Seat Audio Controller	90980-12200	S32	Seat ECU	90980-10801	
R58	Rain Sensor	90980-12263	T 1	Temp. Sensor (AHC)	90980-10737	
R59	Rear Cooler Blower Resistor	90980-10171	T 2	Theft Deterrent Horn	90980-10619	
R60	Rear Fog Light	90980-10860	T 3	Throttle Control Motor	90980-11144	
R61	Roll Sensing of Curtain Shield Airbags Cut Off SW	90980-10957	T 4	Throttle Position Sensor	90980-11261	
			T 5	Timing Control Valve	90980-10720	
S 1	Speed Sensor (Combination Meter)	90980-11143	T 6	Turbo Pressure Sensor	90980-10845	
S 2	Speed Sensor (ECT)	90980-11156	T 8	Telescopic Motor	90980-10799	
S 3	Spill Valve	90980-11155	T 9	Theft Deterrent ECU	90980-12169	
S 4	Starter (1FZ-FE)	90980-09506	T11	Tilt and Telescopic ECU	90980-10799	
	Starter (1HD-FTE, 1HZ)	90980-09508	T12	Tilt and Telescopic ECU	90980-10848	
	Starter (2UZ-FE)	90980-09585	T13	Tilt Motor	90980-10799	
S 5	Starter (1HD-FTE, 1HZ)	90980-11184	T14	Ignition Key Cylinder Light	90980-12092	
	Starter (2UZ-FE, 1FZ-FE)	90980-11400		Transponder Key Amplifier		
S 6	Stop Light SW	90980-11118	T15	Transponder Key Computer (1HZ)	90980-12183	
				Transponder Key Computer (2UZ-FE, 1FZ-FE, 1HD-FTE)	90980-11911	
			T16	Turn Signal Flasher	90980-10799	

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
T17	Tire Carrier Courtesy SW	90980-10870	Z10	Option Connector (Wireless Door Lock Buzzer)	90980-11051
T19	Tweeter LH	90980-11300			
T20	Tweeter RH				
T22	TVSS ECU	90980-10803			
T23	Throttle Control Motor and Sensor	90980-11858			
T24	Throttle Position Sensor and Timing Control Valve	90980-11599			
T25	Turbine Speed Sensor	90980-11156			
T26	Theft Deterrent Siren	90980-11349			
T27	Television Camera	90980-12381			
T28	Television Camera ECU	90980-12169			
T29	Television Camera ECU	90980-10997			
U 1	Unlock Warning SW	90980-10860			
V 1	Vacuum Sensor	90980-10845			
V 2	Vacuum SW	90980-11252			
V 3	Variable Resistor	90980-10902			
V 4	Viscous Heater Magnetic Clutch	90980-11271			
V 6	VRV (EGR)	90980-11162			
V 7	VSV (A/C Idle-Up)	90980-11156			
V 8	VSV (EGR Cut) (1HD-FTE)	90980-11149			
	VSV (EGR Cut) (1HZ)	90980-11156			
V 9	VSV (EVAP)	90980-11156			
V11	VSV (Turbo Pressure Sensor)				
V12	Viscous Heater Amplifier	90980-10801			
V13	VSC Warning Buzzer	90980-10906			
V14	VRV (EGR No.2)	90980-11162			
V15	VSV (BACS)	90980-11156			
V16	VGRS ECU	90980-12120			
V17	VGRS ECU	90980-11915			
V18	Vanity Light LH	90980-11918			
V19	Vanity Light RH				
V20	VGRS Actuator	90980-10993			
W 2	Washer Motor	90980-11294			
W 3	Water Temp. Sender	90980-11428			
W 4	Water Temp. Sensor (Glow Plug)	90980-10737			
W 5	Water Temp. SW (A/C)	90980-10184			
W 7	Winch Main Relay	90980-10887			
W 8	Winch Main Relay	-			
W 9	Winch Main Relay				
W10	Winch Motor and Magnetic SW	90980-10887			
W11	Winch Motor and Magnetic SW	90980-09552			
W13	Woofer (Speaker)	90980-10795			
Z 1	Option Connector (Glass Breakage Sensor)	90980-10799			
Z 3	Option Connector (Radar Sensor)	90980-11013			
Z 8	Option Connector (Microphone)	90980-11368			
Z 9	Option Connector (Trailer Towing)	90980-10988			

Note: Not all of the above part numbers of the connector are established for the supply.

