

## PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
Engine does not crank (Does not start)	1. Starter 2. Starter relay 3. Park/neutral position switch	ST-17*1 ST-19*1 DI-32*2
No initial combustion (Does not start)	1. Engine control ECU power source circuit 2. Fuel pump control circuit 3. Engine control ECU	DI-237 DI-242 IN-20
No complete combustion (Does not start)	1. Fuel pump control circuit	DI-242
Engine cranks normally but difficult to start	1. Starter signal circuit 2. Fuel pump control circuit 3. Compression	DI-228 DI-242 EM-5*1
Difficult to start with cold engine	1. Starter signal circuit 2. Fuel pump control circuit	DI-228 DI-242
Difficult to start with hot engine	1. Starter signal circuit 2. Fuel pump control circuit	DI-228 DI-242
High engine idle speed (Poor idling)	1. A/C switch circuit 2. Engine control ECU power source circuit	– DI-237
Low engine idle speed (Poor idling)	1. A/C switch circuit 2. Fuel pump control circuit	– DI-242
Rough idling (Poor idling)	1. Compression 2. Fuel pump control circuit	EM-5*1 DI-242
Hunting (Poor idling)	1. Engine control ECU power source circuit 2. Fuel pump control circuit	DI-237 DI-242
Hesitation/Poor acceleration (Poor driveability)	1. Fuel pump control circuit 2. A/T faulty	DI-242 DI-5*3
Surging (Poor driveability)	1. Fuel pump control circuit	DI-242
Engine stalls soon after starting	1. Fuel pump control circuit	DI-242
Engine stalls during A/C operation	1. A/C switch circuit 2. Engine control ECU	– IN-20
Unable to refuel/Difficult to refuel	1. ORVR system	–

\*1: See Pub. No. RM630E

\*2: See Pub. No. RM970E

\*3: See Pub. No. RM1072E