

<b>DTC</b>	<b>P1121/19</b>	<b>Accel. Position Sensor Circuit (IDL SW/Range)</b>
------------	-----------------	--

## CIRCUIT DESCRIPTION

Refer to DTC P1120/19 on [page DI-67](#).

DTC No.	DTC Detection Condition	Trouble Area
P1121/19	Condition (a) or (b) continues 0.05 sec. or more: (a) IDL ON and VA > 1.4 V (b) IDL ON and VAS > 1.4 V	<ul style="list-style-type: none"> <li>• Open or short in accelerator pedal position sensor circuit</li> <li>• Accelerator pedal position sensor</li> <li>• Engine ECU</li> </ul>
	Condition (a) or (b) continues 0.5 sec. or more: (a) IDL OFF and VA < 0.6 V (b) IDL OFF and VAS < 0.6 V	
	Conditions (a) and (b) continue 0.05 sec. or more: (a) 0.6 V < VA < 4.4 V and 0.6 V < VAS < 4.4 V (b) VA – VAS > 0.5 V	

## WIRING DIAGRAM

Refer to DTC P1120/19 on [page DI-67](#).

## INSPECTION PROCEDURE

**When using intelligent tester II:**


<b>1</b>	<b>Connect intelligent tester II and read IDL signal.</b>
----------	---

### PREPARATION:

- Connect the intelligent tester II to the DLC3.
- Turn the ignition switch ON and push the intelligent tester II main switch ON.

### CHECK:

Read the IDL signal.



FI7052


### OK:

Accelerator pedal	IDL signal
Fully open	OFF
Fully closed	ON

**OK** Goto step 4.

**NG**

## 2 Check voltage between terminals IDL and E2C of engine ECU.



### PREPARATION:

- (a) Remove the glove compartment door.
- (b) Turn the ignition switch ON.

### CHECK:

Measure the voltage between terminals IDL and E2C of the engine ECU.

### OK:

Accelerator pedal	Voltage
Fully closed	9 to 14 V
Fully open	0 to 3 V

OK

Check and replace engine ECU  
(See page IN-19).

NG

## 3 Check for open and short in harness and connector between engine ECU and accelerator pedal position sensor (IDL line) (See page IN-19).

NG

Repair or replace harness or connector.

OK


Replace accelerator pedal position sensor.

**4 Connect intelligent tester II, and read accelerator pedal operating percentage.****PREPARATION:**

- (a) Connect the intelligent tester II to the DLC3.  
(b) Turn the ignition switch ON and push the intelligent tester II main switch ON.

**CHECK:**

Read the accelerator pedal opening percentage.

**OK:**

Accelerator pedal	Accelerator pedal opening position expressed as percentage
Fully open	Approx. 65%
Fully closed	Approx. 18%

**OK**

**Check for intermittent problems**  
(See page DI-4).

**NG****5 Check voltage between terminal VCC of wire harness side connector and body ground (See page DI-67, Step 2).****NG**

**Go to step 8.**

**OK****6 Check voltage between terminals VA, VAS and E2C of engine ECU (See page DI-67, Step 3).****OK**

**Check and replace engine ECU**  
(See page IN-19).

**NG****7 Check for open and short in harness and connector between engine ECU and accelerator pedal position sensor (VA, VAS line) (See page IN-19).****NG**

**Repair or replace harness or connector.**

OK

Replace accelerator pedal position sensor.

- 8 Check voltage between terminals VCC and E2C of engine ECU  
(See page DI-67, Step 5).

NG


Check and replace engine ECU  
(See page IN-19).

OK

Check for open in harness and connector between engine ECU and accelerator pedal position sensor (VCC line) (See page IN-19).

**When not using intelligent tester II:**

- 1 Check voltage between terminals IDL and E2C of engine ECU.

**PREPARATION:**

- (a) Remove the glove compartment door.  
(b) Turn the ignition switch ON.

**CHECK:**

Measure the voltage between terminals IDL and E2C of the engine ECU.

**OK:**

Accelerator pedal	Voltage
Fully closed	9 to 14 V
Fully open	0 to 3 V

OK

Go to step 3.

NG

- 2 Check for open and short in harness and connector between engine ECU and accelerator pedal position sensor (IDL line) (See page IN-19).

NG

Repair or replace harness or connector.

OK

Replace accelerator pedal position sensor.

- 3 Check voltage between terminal 4 of wire harness side connector and body-ground ([See page DI-67](#), Step 2).

NG

Go to step 6.

OK

- 4 Check voltage between terminals VA, VAS and E2C of engine ECU ([See page DI-67](#), Step 3).

OK

Check and replace engine ECU ([See page IN-19](#)).

NG

- 5 Check for open and short in harness and connector between engine ECU and accelerator pedal position sensor (VA, VAS line) ([See page IN-19](#)).

NG

Repair or replace harness or connector.

OK

Replace accelerator pedal position sensor.

- 6 Check voltage between terminals VCC and E2C of engine ECU ([See page DI-67](#), Step 5).

NG

Check and replace engine ECU ([See page IN-19](#)).

OK

Check for open in harness and connector between engine ECU and accelerator pedal position sensor (VCC line) ([See page IN-19](#)).