



TROUBLESHOOTING W/VOLT, OHMMETER (A/T)

EG060-03

HINT:

- The following troubleshooting procedures are designed for inspection of each separate system, and therefore the actual procedure may vary somewhat. However, troubleshooting should be performed while referring to the inspection methods described in this manual.
- Before beginning inspection, it is best to first make a simple check of the fuses, H—fuses, fusible links and the condition of the connectors.
- The following troubleshooting procedures are based on the supposition that the trouble lies in either a short or open circuit within the computer.
- If engine trouble occurs even though proper operating voltage is detected in the computer connector, then it can be assumed that the ECU is faulty and should be replaced.

EG



EFI SYSTEM CHECK PROCEDURE

EG06A-03

PREPARATION

- Disconnect the connectors from the ECU.
- Remove the locks as shown in the illustration so that the tester probe(s) can easily come in.

NOTICE: Pay attention to sections "A" and "B" in the illustration which can be easily broken.

- Reconnect the connectors to the ECU.
- Using a voltmeter with high impedance (10 k Ω /V minimum), measure the voltage at each terminal of the wiring connectors.


HINT:

- Perform all voltage measurements with the connectors connected.
- Verify that the battery voltage is 11 V or more when the ignition switch is in "ON" position.

ECU Terminals (For A/T)

Symbol	Connection	Symbol	Connection	Symbol	Connection
E01	POWER GROUND	/	—	HT2 *	NO.2 HEATED OXYGEN SENSOR
E02	POWER GROUND	E11	ECU GROUND	/	—
# 10	INJECTOR (No.1)	TE1	Check Connector	STA	NSW SWITCH
# 30	INJECTOR (No.3)	TE2	Check Connector	NSW	IGNITION SWITCH
# 20	INJECTOR (No.2)	KNK1	NO.1 KNOCK SENSOR	NEO	ECT ECU
E1	ECU GROUND	KNK2	NO.2 KNOCK SENSOR	/	—
# 40	INJECTOR (No.4)	OX1	NO.1 OXYGEN SENSOR	VA	ECT ECU
IGT	IGNITER	OX2 *	NO.2 OXYGEN SENSOR	ECT1	ECT ECU
IPV	VSV FOR EVAP	THW	WATER TEMP. SENSOR	SPD	VEHICLE SPEED SENSOR
EGR *	VSV FOR EGR	OX +	OXYGEN SENSORS	ECT2	ECT ECU
AS *	VSV FOR AS	THA	AIR FLOW METER	A/C	A/C AMPLIFIE
FPU	VSV FOR FUEL PRESSURE CONTROL	IDL	TP SENSOR	ECT	ECT ECU
ISC1	ISC VALVE (No.1 Motor Coil)	VS	AIR FLOW METER	/	—
/	—	VTA	TP SENSOR	ESA1	ECT ECU
ISC2	ISC VALVE (No.2 Motor Coil)	VCC	TP SENSOR	/	—
/	—	E2	SENSOR GROUND	ESA2	ECT ECU
ISC3	ISC VALVE (No.3 Motor Coil)	G ⊖	DISTRIBUTOR	W	"CHECK" ENGINE WARNING LIGHT
/	—	NE	DISTRIBUTOR	ESA3	ECT ECU
ISC4	ISC VALVE (No.4 Motor Coil)	/	—	M-REL	EFI MAIN RELAY (COIL)
IGF	IGNITER	G1	DISTRIBUTOR	STP	STOP LIGHT SWITCH
FPR	FUEL PUMP RELAY	/	—	BATT	BATTERY B +
VF2	Check Connector	G2	DISTRIBUTOR	IGSW	IGNITION SWITCH
# 50	INJECTOR (No.5)	/	—	+B1	EFI MAIN RELAY
VF1	Check Connector	/	—	+B	EFI MAIN RELAY
# 60	INJECTOR (No.6)	HT1	NO.1 OXYGEN SENSOR	* Only for Europe.	
/	—	/	—		


ECU Terminals




ECU Wiring Connectors Voltage (For A/T)

No.	Terminals	Condition		STD voltage (V)	See page
1	BATT — E1	—		9 — 14	EG-203
	IG SW — E1	IG SW ON			
	M-REL — E1				
	+B +B1 — E1				
2	IDL — E2	IG SW ON	Throttle valve open	9 — 14	EG-204
	VCC — E2		—	4.5 — 5.5	
	VTA — E2		Throttle valve fully closed (Throttle opener must be cancelled first)	0.3 — 0.8	
			Throttle valve fully open	3.2 — 4.9	
3	VCC — E2	IG SW ON	—	4.5 — 5.5	EG-208
	VS — E2		Measuring plate fully closed	3.5 — 4.5	
			Measuring plate fully open	0.2 — 0.5	
			Idling	1.2 — 2.4	
	3,000 rpm		0.8 — 1.3		
4	#10 } — E01 #60 E02	IG SW ON		9 — 14	EG-209
5	THA — E2	IG SW ON	Intake air temp. 20°C (68°F)	0.5 — 3.4	EG-210
6	THW — E2		Engine coolant temp. 80°C (176°F)	0.2 — 1.0	EG-211
7	STA — E1	Cranking		6 or more	EG-212
8	IGT — E1	Idling		Pulse generation	EG-213
9	ISC1 } — E1 ISC4	IG SW ON		9 — 14	EG-214
10	W — E1	No trouble (malfunction indicator lamp light off) and engine running		9 — 14	EG-215


ECM Terminals




No.	Terminals	Trouble	Condition	STD voltage
1	BATT – E1	No voltage	—	9 – 14 V
	IG SW – E1	No voltage	IG SW ON	9 – 14 V
	M-REL – E1			
	+ B (+ B1) – E1			




P01652



P00762



P00761



P00739

• BATT – E1

① There is no voltage between ECU terminals BATT and E1.

② Check that there is voltage between ECU terminal BATT and body ground.

NO

OK

③ Check wiring between ECU terminal E1 and body ground.

OK

BAD

Try another ECU.

Repair or replace.

Check fuse and fusible link.

BAD

Replace.





OK

Check wiring between ECU terminal and battery.

BAD

Repair or replace.

EG



• IG SW – E1

① There is no voltage between ECU terminals IG SW and E1. (IG SW ON)

② Check that there is voltage between ECU terminal IG SW and body ground. (IG SW ON)

NO

OK

Check wiring between ECU terminal E1 and body ground.

OK

BAD

Try another ECU.

Repair or replace.

Check fuses, fusible link and ignition switch.

BAD

Repair or replace.

• M-REL – E1

① There is no voltage between ECU terminals M-REL and E1. (IG SW ON)

② Check that there is voltage between ECU terminal M-REL and body ground. (IG SW ON)

NO

OK

Check wiring between ECU terminal E1 and body ground.

OK

BAD

Try another ECU.

Repair or replace.



Check EFI main relay and wiring harness. (See page EG-272)

BAD

Replace.

OK

Try another ECU.



• +B (+B1) — E1

① There is no voltage between ECU terminals +B (+B1) and E1. (IG SW ON)

② Check that there is voltage between ECU terminal +B (+B1) and body ground. (IG SW ON)

NO

OK

Check wiring between ECU terminal E1 and body ground.

OK

BAD

Try another ECU.

Repair or replace.

Check fuse, fusible link and wiring harness.

BAD

Repair or replace.

OK

Check EFI main relay.
(See page EG-272)

BAD


Replace.

OK


Refer to M-REL — E1 trouble section.

EG


No.	Terminals	Trouble	Condition		STD voltage
2	IDL — E2	No voltage	IG SW ON	Throttle valve open	9 — 14 V
	VCC — E2			—	4.5 — 5.5 V
	VTA — E2			Throttle valve fully closed (Throttle opener must be cancelled first)	0.3 — 0.8 V
				Throttle valve fully open	3.2 — 4.9 V




P01419



P00756





P01264






P09282

• IDL - E2









• VC - E2






• VTA - E2



No.	Terminals	Trouble	Condition		STD voltage
3	VCC — E2	No voltage	IG SW ON	—	4.5 — 5.5 V
	VS — E2			Measuring plate fully closed	3.5 — 4.5 V
	VS — E2			Measuring plate fully open	0.2 — 0.5 V
	VS — E2		Idling		1.2 — 2.4 V
	VS — E2		3,000 rpm		0.8 — 1.3 V



FI6032



① There is no voltage between ECU terminals VCC or VS and E2. (IG SW ON)

② Check that there is voltage between ECU terminal +B (+B1) and body ground. (IG SW ON)

OK

NO

Refer to No.1
(See page EG-203)

Check wiring between ECU terminal E1 and body ground.

OK

BAD

③ Check Air Flow meter.
(See page EG-267)

BAD

Replace Air
Flow meter.

OK

Check wiring between ECU and Air
Flow meter.


OK

Try another ECU.


BAD

Repair or replace.


No.	Terminals	Trouble	Condition	STD voltage
4	# 10 E01 } — # 60 E02	No voltage	IG SW ON	9 – 14 V




P09298




P00752





P00764



P09535






① There is no voltage between ECU terminals THA and E2. (IG SW ON)

② Check that there is voltage between ECU terminal +B (+B1) and body ground. (IG SW ON)

OK

NO

Refer to No. 1
(See page EG-203)



Check wiring between ECU terminal E1 and body ground.

OK

BAD

③ Check Intake air temp. sensor. (See page EG-268)

Repair or replace.

BAD

Replace Air Flow meter.


Check wiring between ECU and Intake air temp. sensor.

OK


BAD

Try another ECU.

Repair or replace.




No.	Terminals	Trouble	Condition		STD voltage
6	THW — E2	No voltage	IG SW ON	Engine coolant temperature 80 °C (176 °F)	0.2 — 1.0 V



F13572

EG



① There is no voltage between ECU terminals THW and E2. (IG SW ON)

② Check that there is voltage between ECU terminal +B (+B1) and body ground. (IG SW ON)

OK

NO

Refer to No.1
(See page EG-203)

Check wiring between ECU terminal E1 and body ground.

OK

BAD

③ Check Water temp. sensor.
(See page EG-275)

Repair or replace.

BAD

OK

Replace Water temp.
sensor.



Check wiring between ECU and
ECT sensor.

OK


BAD

Try another ECU.


Repair or replace.




No.	Terminals	Trouble	Condition	STD voltage
8	STA - E1	No voltage	Cranking	6 V or more




P07570




P00749




P00739




P09619




No.	Terminals	Trouble	Condition	STD voltage
8	IGT — E1	No voltage	Idling	False generation




P04541




P09363







P09361



P00739





① There is no voltage between ECU terminals ISC1 ~ ISC4 and E1. (IG SW ON)

② Check that there is voltage between ECU terminal +B (+B1) and body ground (IG SW ON)

OK

NO

Refer to No. 1
(See page EG-203)

Check wiring between ECU terminal E1 and body ground.

OK

BAD

③ Check ISC valve.
(See page EG-269)

Repair or replace.

BAD

Replace ISC valve

OK

Check wiring between ECU and EFI main relay.


OK

BAD

Try another ECU.


Repair or replace.

No.	Terminals	Trouble	Condition	STD voltage
10	W — E1	No voltage	No trouble (malfunction indicator lamp light off) and engine running.	9 — 14 V




F10728

EG



① There is no voltage between ECU terminals W and E1. (Idling)



② Check that there is voltage between ECU terminal W and body ground.

NO

OK

③ Check wiring between ECU terminal E1 and body ground.

OK

BAD

Try another ECU.

Repair or replace.

Check GAUGE fuse (10A) and malfunction indicator lamp.

OK

BAD


Repair or replace.

Fuse blows again


Check wiring between ECU terminal W and fuse.

BAD




Repair or replace.



No.1 Oxygen Sensor




P09365




V02829



No.2 Oxygen Sensor



P09413



P09362

P09137
P09617

V02830