


## ON—VEHICLE INSPECTION SPARK TEST


IG00V-02

### CHECK THAT SPARK OCCURS

- Disconnect the high—tension cords (from the ignition coil) from the distributor cap.
- Hold the end approx. 12.5 mm (0.50 in.) from the body ground.
- Check if spark occurs while engine is being cranked. If the spark does not occur, perform the test as follows:

IG






## HIGH — TENSION CORDS INSPECTION


### 1. REMOVE INTAKE AIR CONNECTOR

- (a) Disconnect the PCV hose.
- (b) Remove the two bolts, nut and air connector.




### 2. REMOVE NO. 2 AND NO. 3 CYLINDER HEAD COVERS

Remove the four bolts and head covers.



### 3. DISCONNECT HIGH — TENSION CORDS FROM SPARK PLUGS


- (a) Remove the No.1 cord clamp mounting bolt.



- (b) Disconnect the high — tension cords at the rubber boot.


DO NOT pull on the cords.

**NOTICE:** Pulling on or bending the cords may damage the conductor inside.



### 4. DISCONNECT HIGH—TENSION CORDS FROM DISTRIBUTOR CAP AND IGNITION COIL


- (a) Using a screwdriver, lift up the lock claw and disconnect the holder from the distributor cap (ignition coil).



- (b) Disconnect the high—tension cord at the grommet. DO NOT pull on the cord.

**NOTICE:**

- Pulling on or bending the cords may damage the conductor inside.
- Do not wipe any of the oil from the grommet after the high—tension cord is disconnected.




**5. INSPECT HIGH—TENSION CORD RESISTANCE**

Using an ohmmeter, measure the resistance.

**Maximum resistance:**


**25 kΩ per cord**

If the resistance is greater than maximum, check the terminals. If necessary, replace the high — tension cord.




**6. RECONNECT HIGH—TENSION CORDS TO DISTRIBUTOR CAP AND IGNITION COIL**


- (a) Insert the grommet portion into the terminal hole of the distributor cap (ignition coil).



- (b) Align the spline of the distributor (ignition coil) with the spline of the holder, and slide on the holder.



**NOTICE:** Check that the holder is correctly installed to the grommet and distributor cap as shown in the illustration.





- (c) Check that the lock claw of the holder is engaged by lightly pulling the holder.
- (d) Insert the grommet and holder together.


IG

## 7. RECONNECT HIGH—TENSION CORDS TO SPARK PLUGS

- (a) Secure the high—tension cords with the clamps as shown in the illustration.




- (b) Install the No.1 cord clamp with the bolt.



## 8. INSTALL NO. 2 AND NO. 3 CYLINDER HEAD COVERS

Install the head covers with the four bolts.



## 9. INSTALL INTAKE AIR CONNECTOR

(a) Install the air connector with the two bolts and nut.

**Bolt**


**Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)**

**Nut**

**Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)**

(b) Connect the PCV hose.

IG




## SPARK PLUGS INSPECTION

IG03F-01

## 1. REMOVE NO. 2 AND NO. 3 CYLINDER HEAD COVERS

Remove the four bolts and head covers.




## 2. DISCONNECT HIGH — TENSION CORDS FROM SPARK PLUGS

Disconnect the high — tension cords at the rubber boot.

**DO NOT** pull on the cords.


**NOTICE:** Pulling on or bending the cords may damage the conductor inside.



## 3. REMOVE SPARK PLUGS

Using SST, remove the spark plug.


SST 09155—16100



IG0152

#### 4. CLEAN SPARK PLUGS

Using a spark plug cleaner or wire brush, clean the spark plug.



P03783

#### 5. VISUALLY INSPECT SPARK PLUGS


Check the spark plug for electrode wear, threads damage and insulator damage.

If abnormal, replace the plugs.

**Recommended spark plugs:**

ND K16R—U

NGK BKR5EYA




P03792

#### 6. ADJUST ELECTRODE GAP

Carefully bend the outer electrode to obtain the correct electrode gap.

**Correct electrode gap:**

0.8 mm (0.031 in.)



P03837


#### 7. INSTALL SPARK PLUGS

Using SST, install the spark plug.

SST 09155—16010

Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)

#### 8. RECONNECT HIGH—TENSION CORDS TO SPARK PLUGS



P04997

#### 9. INSTALL NO. 2 AND NO. 3 CYLINDER HEAD COVERS

Install the head covers with the four bolts.

## IGNITION COIL INSPECTION

**NOTICE:** "Cold" and "Hot" in the following sentences express the temperature of the coils themselves. "Cold" is from  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ ) to  $50^{\circ}\text{C}$  ( $122^{\circ}\text{F}$ ) and "Hot" is from  $50^{\circ}\text{C}$  ( $122^{\circ}\text{F}$ ) to  $100^{\circ}\text{C}$  ( $212^{\circ}\text{F}$ ).

1. DISCONNECT IGNITION COIL CONNECTOR
2. DISCONNECT HIGH—TENSION CORD

IG

## 3. INSPECT PRIMARY COIL RESISTANCE

Using an ohmmeter, measure the resistance between the positive (+) and negative (—) terminals.


Primary coil resistance (Cold):

$0.36 - 0.55 \Omega$

Primary coil resistance (Hot):

$0.45 - 0.65 \Omega$

If the resistance is not as specified, replace the ignition coil.



## 4. INSPECT SECONDARY COIL RESISTANCE

Using an ohmmeter, measure the resistance between the positive (+) and high—tension terminals.


Secondary coil resistance (Cold):

$9.0 - 15.4 \text{ k}\Omega$

Secondary coil resistance (Hot):

$11.4 - 18.1 \text{ k}\Omega$

If the resistance is not as specified, replace the ignition coil.




5. RECONNECT HIGH—TENSION CORD
6. RECONNECT IGNITION COIL CONNECTOR


## DISTRIBUTOR INSPECTION

**NOTICE:** "Cold" and "Hot" in the following sentences express the temperature of the coils themselves. "Cold" is from  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ ) to  $50^{\circ}\text{C}$  ( $122^{\circ}\text{F}$ ) and "Hot" is from  $50^{\circ}\text{C}$  ( $122^{\circ}\text{F}$ ) to  $100^{\circ}\text{C}$  ( $212^{\circ}\text{F}$ ).


IG



1. **DISCONNECT DISTRIBUTOR CONNECTOR**
2. **REMOVE DISTRIBUTOR CAP WITHOUT DISCONNECTING HIGH-TENSION CORDS**



3. **REMOVE ROTOR**  
Remove the screw and rotor.
4. **REMOVE DUST PROOF COVER**



### 5. INSPECT AIR GAP

Using a thickness gauge, measure the gap between the signal rotor and the pickup coil projection.

**Air gap:**

**0.2 — 0.4 mm (0.008 — 0.016 in.)**

If the gap is not within specification, adjust the gap.

- Loosen the two screws and move the signal generator (pickup coil) until the gap is correct. Tighten the screws and recheck the gap.

### 6. INSPECT SIGNAL GENERATOR (PICKUP COIL) RESISTANCE

Using an ohmmeter, check that the resistance of the pickup coil.


**Pickup coil resistance (Cold):**

**185 — 275  $\Omega$**


**Pickup coil resistance (Hot):**

**240 — 325  $\Omega$**

If the resistance is not as specified, replace the signal generator (pickup coil).








## 7. INSPECT VACUUM ADVANCE

- (a) Disconnect the vacuum hose and connect a vacuum pump to the vacuum advancer.
- (b) Apply vacuum and check that the vacuum advancer moves.

If the vacuum advancer does not work, repair or replace if necessary.


IG



## 8. INSPECT GOVERNOR ADVANCE


- (a) Turn the rotor shaft counterclockwise, release it and check that the rotor returns quickly clockwise.
- (b) Check that the rotor is not excessively loose.

## 9. INSTALL DUST PROOF COVER



## 10. REINSTALL ROTOR

Install the rotor with the screw.



## 11. REINSTALL DISTRIBUTOR CAP

## 12. RECONNECT DISTRIBUTOR CONNECTOR

## IGNITER INSPECTION

IG00Z-01

(See Spark Test procedure on page IG—25)