



INSTALLATION

1. CHECK TORQUE CONVERTER INSTALLATION

Using calipers and a straight edge, measure the distance from the installed surface of the transmission housing to the installed surface of the torque converter.

Correct distance: More than 15.7 mm (0.618 in.)

2. TRANSMISSION INSTALLATION

Installation is in the reverse order of removal

([See page AT-30](#)).

HINT:

- After installation, adjust the shift lever position ([See page DI-4](#)).
- Fill ATF and check fluid level ([See page DI-4](#)).
- Conduct the road test of the vehicle ([See page DI-4](#)).