



## ATF TEMPERATURE SENSOR (2UZ-FE)

AT09F-01

### ON-VEHICLE REPAIR

1. REMOVE NO.2 ENGINE UNDER COVER
2. REMOVE FRONT PROPELLER SHAFT  
(See page PR-4)
3. DISCONNECT ATF TEMPERATURE SENSOR CONNECTOR
4. REMOVE ATF TEMPERATURE SENSOR
  - (a) Remove the ATF temperature sensor.
  - (b) Remove the O-ring from the sensor.
5. INSTALL ATF TEMPERATURE SENSOR
  - (a) Coat a new O-ring with ATF and install it to the ATF temperature sensor.
  - (b) Install the ATF temperature sensor.
6. CONNECT ATF TEMPERATURE SENSOR CONNECTOR
7. INSTALL FRONT PROPELLER SHAFT  
(See page PR-7)
8. INSTALL NO.2 ENGINE UNDER COVER