



**Wire Harness Side**

Connector "A"



Connector "B"



I06197

**INSPECTION****1. INSPECT RADIO RECEIVER ASSEMBLY CIRCUIT**


Disconnect the connectors from the radio receiver assembly, and inspect the connector on the wire harness side.

Tester connection	Condition	Specified condition
A11 – Ground	Constant	Continuity
B8 – Ground	Constant	Continuity
A4 – Ground	Constant	Battery voltage
B5 – Ground	Constant	Battery voltage
A3 – Ground	Ignition switch LOCK	No voltage
A3 – Ground	Ignition switch ACC or ON	Battery voltage
B12 – Ground	Ignition switch LOCK	No voltage
B12 – Ground	Ignition switch ACC or ON	Battery voltage


If the circuit is not as specified, inspect the circuits connected to other parts.

**HINT:**


Check the wire harness between radio receiver assembly and the CD auto changer, between radio receiver assembly and power amplifier.

**Wire Harness Side**

Connector "A"



Connector "B"



Connector "C"

I06198

**2. INSPECT RADIO RECEIVER ASSEMBLY CIRCUIT**

Disconnect the connectors from the radio receiver assembly, and inspect the connector on the wire harness side.

Tester connection	Condition	Specified condition
B7 – Ground	Constant	Continuity
C8 – Ground	Constant	Continuity
B3 – Ground	Ignition switch LOCK and radio switch ON	No voltage
B3 – Ground	Ignition switch ACC or ON and radio switch ON	Battery voltage
B4 – Ground	Constant	Battery voltage
C5 – Ground	Constant	Battery voltage
C12 – Ground	Ignition switch LOCK and radio switch ON	No voltage
C12 – Ground	Ignition switch ACC or ON and radio switch ON	Battery voltage


If the circuit is not as specified, inspect the circuits connected to other parts.

**HINT:**


Check the wire harness between radio receiver assembly and the CD auto changer, between radio receiver assembly and power amplifier.

**Wire Harness Side**

Connector "A"



Connector "B"



I06196

**3. Except NAKAMICHI made:  
INSPECT POWER AMPLIFIER CIRCUIT**


Disconnect the connector from power amplifier and inspect the connector on the wire harness side.

Tester connection	Condition	Specified condition
A2 – Ground	Ignition switch LOCK and radio switch ON	No voltage
A3 – Ground	Constant	Battery voltage
A9 – Ground	Ignition switch LOCK and radio switch ON	No voltage
A9 – Ground	Ignition switch ACC or ON and radio switch ON	Battery voltage
A10 – Ground B12 – Ground B13 – Ground	Constant	Continuity
B7 – Ground	Constant	Battery voltage
B16 – Ground	Constant	Battery voltage


If the circuit is not as specified, inspect the circuits connected to other parts.

**Wire Harness Side**


Connector "A"




Connector "B"



Connector "C"



Connector "D"




I04309

**4. NAKAMICHI made:****INSPECT POWER AMPLIFIER CIRCUIT**

Disconnect the connector from power amplifier and inspect the connector on the wire harness side.

Tester connection	Condition	Specified condition
A1 – Ground A4 – Ground D1 – Ground	Constant	Continuity
A6 – Ground	Ignition switch LOCK and radio switch ON	No voltage
A6 – Ground	Ignition switch ACC or ON and radio switch ON	Battery voltage
A2 – Ground	Constant	Battery voltage
A5 – Ground	Constant	Battery voltage

If the circuit is not as specified, inspect the circuits connected to other parts.

**Wire Harness Side**

I04188

**5. INSPECT CD AUTO CHANGER CIRCUIT**

Disconnect connectors from CD auto changer and inspect the connector on the wire harness side.

Tester connection	Condition	Specified condition
8 – Ground	Constant	Continuity
12 – Ground	Ignition switch LOCK	No voltage
12 – Ground	Ignition switch ACC or ON	Battery voltage
5 – Ground	Constant	Battery voltage

If the circuit is not as specified, inspect the circuits connected to other parts.

**HINT:**

- Check the wire harness between the radio receiver assembly and the CD auto changer.
- Since the signals to and from the MUTE, R<sup>-</sup>, R<sup>+</sup>, L<sup>-</sup>, L<sup>+</sup>, TX<sup>-</sup> and TX<sup>+</sup> terminals are serial signals, they cannot ordinarily be measured with a tester.