

DIAGNOSTIC TROUBLE CODE CHART

If a DTC is displayed during the DTC check, check the circuit listed in the table below and proceed to the page given.

DTC No. (See Page)	Detection Item	Trouble Area	*1 O/D Indicator Light Blink	*2 Memory
41 (DI-113)	Throttle Position Sensor Circuit	<ul style="list-style-type: none"> • Open or short in throttle position sensor circuit • Throttle position sensor • ECT ECU 	□	□
86 (DI-115)	Engine Revolution Sensor Circuit	<ul style="list-style-type: none"> • Open or short in engine revolution sensor circuit • Engine revolution sensor • ECT ECU 	□	□
88 (DI-117)	Engine ECU Circuit	<ul style="list-style-type: none"> • Open or short in Engine ECU circuit • ECT ECU • Engine ECT 	□	□
P0500/42 (DI-119)	Vehicle Speed Sensor Malfunction (No.1 Speed Sensor)	<ul style="list-style-type: none"> • Open or short in No. 1 speed sensor circuit • No.1 speed sensor • Combination meter • Engine and ECT ECU or ECT ECU • Automatic transmission assembly 	□	□
P0710/38 (DI-124)	Transmission Fluid Temperature Sensor Circuit Malfunction (ATF Temperature Sensor)	<ul style="list-style-type: none"> • Open or short in ATF temperature sensor circuit • ATF temperature sensor circuit • Engine and ECT ECU or ECT ECU 	□	□
P0753/62 (DI-126)	Shift Solenoid "A" Electrical Malfunction (No.1 Solenoid Valve)	<ul style="list-style-type: none"> • Open or short No. 1 solenoid valve circuit • No.1 solenoid valve • Engine and ECT ECU or ECT ECU 	□	□
P0758/63 (DI-126)	Shift Solenoid "B" Electrical Malfunction (No.2 Solenoid Valve)	<ul style="list-style-type: none"> • Open or short No.2 solenoid valve circuit • No.2 solenoid valve • Engine and ECT ECU or ECT ECU 	□	□
P0773/64 (DI-132)	Shift Solenoid "E" Electrical Malfunction (SL Solenoid Valve)	<ul style="list-style-type: none"> • Open or short SL solenoid valve circuit • SL solenoid valve • Engine and ECT ECU or ECT ECU 	□	□
P1700/61 (DI-137)	Speed Sensor No.2 Circuit Malfunction (No.2 Speed Sensor)	<ul style="list-style-type: none"> • Open or short in No.2 speed sensor circuit • No.2 speed sensor • Engine and ECT ECU or ECT ECU 	X	□
P1745/38 (DI-141)	ATF Temperature Sensor No.2 Circuit Malfunction	<ul style="list-style-type: none"> • Open or short in ATF temperature sensor No.2 circuit • ATF temperature sensor No.2 • Engine and ECT ECU or ECT ECU 	□	□
P1760/77 (DI-143)	Linear Solenoid for Line Pressure Control Circuit Malfunction (SLT Solenoid Valve)	<ul style="list-style-type: none"> • Open or short in SLT solenoid valve circuit • SLT solenoid valve • Engine and ECT ECU or ECT ECU 	X	□
P1790/65 (DI-146)	ST Solenoid Valve Circuit Malfunction	<ul style="list-style-type: none"> • Open or short ST solenoid valve circuit • ST solenoid valve • Engine and ECT ECU or ECT ECU 	X	□

*1: "□" mark means O/D OFF indicator light blinks once every 2 seconds.

"X" mark means O/D OFF indicator light never blinks.

*2: "□" mark means Engine and ECT ECU or ECT ECU memorizes the malfunction code if the Engine and ECT ECU or ECT ECU detects the DTC detection condition.

HINT:

This DTC may be output when the clutch, brake and gear components etc. inside the automatic transmission are damaged.