


| | | |
|------------|------------------|---|
| DTC | P07 10/38 | Transmission Fluid Temperature Sensor Malfunction (ATF Temperature Sensor) |
|------------|------------------|---|

CIRCUIT DESCRIPTION

The ATF temperature sensor converts fluid temperature into a resistance value which is input into the Engine and ECT ECU (2UZ -FE, 1FZ -FE) or ECT ECU (1HZ, 1HD -T, 1HD -FTE).


| DTC No. | DTC Detecting Condition | Trouble Area |
|----------|---|---|
| P0710/38 | Either (a) or (b) is detected for 0.5 sec. or more. (2-trip detection logic) (a) Temperature sensor resistance is less than 79 Ω (b) After the engine has been operating for 15 minutes or more, the resistance at the temp. sensor is more than 156 k Ω | <ul style="list-style-type: none"> • Open or short in ATF temperature sensor • ATF temperature sensor • Engine and ECT ECU (2UZ -FE, 1FZ -FE) • ECT ECU (1HZ, 1HD -T, 1HD -FTE) |

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check ATF temperature sensor.

**PREPARATION:**

Remove the ATF temperature sensor ([See page AT-8](#)).

CHECK:

Measure resistance between terminals 1 and 5 of solenoid connector at 10 °C (50 °F) and 110 °C (230 °F).

OK:

Resistance (Approx.):

10 °C (50 °F): 6.5 kΩ

110 °C (230 °F): 200 – 300 Ω

NG

Replace the ATF temperature sensor.

OK

2 Check harness and connector between ATF temperature sensor and Engine and ECT ECU or ECT ECU ([See page IN-35](#)).

NG

Repair or replace the harness or connector.

OK

Check and replace the Engine and ECT ECU or ECT ECU ([See page IN-35](#)).