


DTC	C 1789 / 89	L4 Position Switch Circuit
------------	--------------------	-----------------------------------

CIRCUIT DESCRIPTION

This circuit is sending the signal to the ECU by detecting that the transfer shift lever is in "L4" position.

DTC No.	DTC Detecting Condition	Trouble Area
C1789/89	L4 position switch signal does not change.	<ul style="list-style-type: none"> • L4 position switch • L4 position switch circuit • Suspension control ECU

WIRING DIAGRAM



INSPECTION PROCEDURE

- | | |
|---|---|
| 1 | Check output signal of L4 position switch. |
|---|---|

IN CASE OF USING HAND -HELD TESTER:

PREPARATION:

- Connect the hand -held tester to the DLC3.
- Turn the ignition switch ON and push the hand -held tester main switch ON.
- Select the DATALIST mode on the hand -held tester.

CHECK:

Check the L4 position switch condition displayed on the hand -held tester when shifting the transfer shift lever in "L4" and "H4" positions.


OK:

When the transfer shift lever is shifted in "L4" position:

"ON" is displayed for L4 position switch condition.

When the transfer shift lever is shifted in "H4" position:

"OFF" is displayed for L4 position switch condition.



IN CASE OF NOT USING HAND -HELD TESTER:

PREPARATION:

Remove the suspension control ECU with connectors still connected.

CHECK:

- Turn the ignition switch ON.
- Measure voltage between terminal L4SW of suspension control ECU connector and body ground when transfer shift lever is shifted in "L4" and "H4" position.


OK:

Transfer shift lever position	Voltage
L4	Below 1.5 V
H4	9 – 14 V

OK

No problem.

NG

2 Check L4 position switch.**PREPARATION:**

- Disconnect the L4 position switch connector.
- Remove the L4 position switch ([See page TR-9](#)).

CHECK:

Measure resistance between terminals 1 and 2 of L4 position switch connector when the L4 position switch pushed and released.

OK:

Switch condition	Resistance
Pushed	0 Ω (Continuity)
Released	∞ Ω (Open)

NG**Replace L4 position switch.****OK****3 Check for open and short circuit in harness and connector between L4 position switch and suspension control ECU ([See page IN-35](#)).****NG****Repair or replace harness or connector.****OK****Check and replace suspension control ECU.**