


DTC	RrACSW, HI	Rear Inlet Air Temperature Sensor Circuit
-----	------------	---

CIRCUIT DESCRIPTION

This sensor detects the rear inlet air temperature and sends the appropriate signals to the A/C amplifier.


Blinking light	Detection Item	Trouble Area
RrACSW HI	Open or short in rear inlet air temperature sensor circuit.	<ul style="list-style-type: none">• Rear inlet air temperature sensor.• Harness or connector between rear inlet air temperature sensor and rear A/C amplifier.• Rear A/C amplifier.

WIRING DIAGRAM



INSPECTION PROCEDURE

1	Check voltage between terminals Tinr and SG1 of rear A/C amplifier connector.
---	--

**PREPARATION:**

Remove rear A/C amplifier with connectors still connected.

CHECK:

- (a) Turn ignition switch ON.
- (b) Measure voltage between terminals Tinr and SG1 of rear A/C amplifier connector at each temperature.

OK:

Voltage :

at 25° C (77° F) : 1.8 – 2.2 V

at 40° C (104° F) : 1.2 – 1.6 V

HINT:


As the temperature increases, the voltage decreases.

NG

Go to step 2.

OK

Proceed to next circuit inspection shown on problem symptoms table ([See page DI-859](#)). However, if RrACSW and HI indicator light is light up, check and replace rear A/C amplifier.

2 Check rear inlet air temperature sensor.**PREPARATION:**

Disconnect rear inlet air temperature sensor connector.

CHECK:

Measure resistance between terminals 1 and 2 of rear inlet air temperature sensor connector at each temperature.

OK:**Resistance :**

at 25° C (77° F) : 1.65 – 1.75 k Ω

at 50° C (122° F) : 0.55 – 0.65 k Ω

HINT:

As the temperature increases, the resistance decreases.

NG**Replace rear inlet air temperature sensor.****OK****3 Check harness and connector between rear A/C amplifier and inlet air temperature sensor (See page IN-35).****NG****Repair or replace harness or connector.****OK****Check and replace rear A/C amplifier.**