


## REMOVAL

### 1. REMOVE FRONT WHEEL

**Torque: 209 N·m (2, 131 kgf·cm, 154 ft·lbf)**




### 2. REMOVE STABILIZER BAR

- (a) Remove the nut and disconnect the stabilizer bar with the link from the bracket.

**Torque: 103 N·m ( 1,050 kgf·cm, 76 ft·lbf)**

HINT:

At the time of installation, after stabilizing the suspension, torque the nut.




- (b) Remove the bolt, nut and stabilizer bar from the axle housing.

**Torque: 30 N·m (3 10 kgf·cm, 23 ft·lbf)**

HINT:

At the time of installation, after stabilizing the suspension, torque the nut.



- (c) Remove the 4 bolts, 2 covers, 2 cushions and 2 stabilizer bar links from the stabilizer bar.

**Torque: 18 N·m ( 185 kgf·cm, 13 ft·lbf)**

HINT:

At the time of installation, please refer to the following item. Install the cushions on the lines painted on the stabilizer bar and install the covers onto cushions.

- (d) Remove the 2 collars, bushings from the stabilizer bar.