

## REMOVAL

### 1. REMOVE REAR WHEEL

**Torque: 209 N·m (2,131 kgf·cm, 154 ft·lbf)**

### 2. SUPPORT AXLE HOUSING WITH JACK

### 3. REMOVE REAR SHOCK ABSORBER

- (a) Remove the lower bolt holding the shock absorber from the rear axle housing.


**Torque: 64 N·m (650 kgf·cm, 47 ft·lbf)**

- (b) Remove the retainer and 2 cushions, disconnect the shock absorber.

- (c) Remove the 2 upper bolts and shock absorber.

**Torque: 50 N·m (510 kgf·cm, 37 ft·lbf)**


- (d) Remove the nut, 2 cushions, 3 retainers and bracket from the shock absorber.



### 4. DISCONNECT LH AND RH STABILIZER BAR BRACKETS

Remove the 4 bolts and disconnect the LH and RH stabilizer bar brackets.

**Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)**



### 5. DISCONNECT LATERAL CONTROL ROD

Remove the nut, washer, bolt and disconnect the lateral control rod.

**Torque: 177 N·m (1,800 kgf·cm, 130 ft·lbf)**

#### HINT:

At the time of installation, after stabilizing the suspension, torque the nut and bolt.


### 6. DISCONNECT BREATHER HOSE

### 7. REMOVE COIL SPRING

- (a) Begin to lower the axle housing.

#### NOTICE:

**Be careful not to snap the brake line and parking cable.**




- (b) While lowering the axle housing, remove the coil spring and insulator.

HINT:

At the time of installation, please refer to the following items.

- Check that the coil spring end is installed correctly.
- If the coil spring end is not in the correct position, reinstall the coil spring.



- (c) Remove the bolt and follow spring from the frame.  
**Torque: 28 N·m (290 kgf·cm, 21 ft·lbf)**