

DISASSEMBLY

1. DRAIN WINCH FLUID


- Using a hexagon wrench, remove the drain plug.
- Drain the winch fluid.

2. REMOVE WIRE HOLDER

3. REMOVE WINCH WIRE


- Shift the shift lever to the free position.
- Pull out the winch wire from the winch drum.

- Using a hexagon wrench, remove the set bolt.
- Remove the winch wire.




4. REMOVE WINCH MOTOR ASSEMBLY

- Remove the 2 bolts and winch motor assembly.
- Remove the O-ring.




5. REMOVE WINCH BRAKE CASE


Remove the winch brake case, winch drum No. 1 spacer and bushing drum.



6. REMOVE WINCH DRUM

- Remove the outer clutch with the inner clutch.
- Remove the winch drum and bushing drum from the gear case assembly.






H05418

7. REMOVE OUTER CLUTCH


- Using a screwdriver, remove the snap ring.
- Remove the input shaft thrust washer.
- Remove the clutch input shaft and clutch thrust waster.



H05419

8. REMOVE ONE -WAY CLUTCH


- Using snap ring pliers, remove the snap ring.
- Remove the one -way clutch.
- Remove the X -ring.
- Using a screwdriver, pry out the oil seal.



H05420

9. REMOVE GEAR CASE COVER


Using a hexagon wrench, remove the gear case cover and gasket.



H06513


10. REMOVE PLANETARY GEAR NO. 1, NO.2 AND NO.3 AND DRIVE SHAFT

- Using a screwdriver, remove the snap ring.
- Remove the thrust washer.
- Remove the X -ring.




H06514


- Pull out the drive shaft, then remove the planetary gear No.1, No.2 and No.3.

**11. REMOVE CLUTCH SHAFT**

Remove the bolt and clutch shaft.

**12. REMOVE WINCH SLEEVE**

Remove the winch sleeve.

**13. REMOVE OUTPUT SHAFT**

- (a) Using a snap ring expander, remove the snap ring and drum spacer No.2.
- (b) Remove the output shaft and spacer.