



## INSPECTION

### INSPECT ISC VALVE OPERATION

- (a) Check that the ISC valve is halfly opened.
- (b) Connect the ISC valve connector to the ISC valve.
- (c) Turn the ignition switch ON.
- (d) Check that the ISC valve moves in 0.5 seconds by order of fully open, fully close and halfly open.

If operation is not as specified, replace the ISC valve.

- (e) Turn the ignition switch OFF.
- (f) Disconnect the ISC valve connector from the ISC valve.