


INSPECTION

1. **DISCONNECT AIR FLOW METER CONNECTOR**
2. **REMOVE AIR FLOW METER**

Remove the 2 screws and MAF meter.




3. **INSPECT AIR FLOW METER**

- (a) Using an ohmmeter, measure the resistance between terminals THA and E2.

Terminals	Resistance	Temperature
THA - E2	12.5 - 16.9 kΩ	-20°C (-4°F)
THA - E2	2.19 - 2.67 kΩ	20°C (68°F)
THA - E2	0.50 - 0.68 kΩ	60°C (140°F)

If the resistance is not as specified, replace the air flow meter.



- (b) Inspect for operation.

- (1) Connect the air flow meter connector.
- (2) Connect the negative (-) terminal cable to the battery.
- (3) Turn the ignition switch ON.
- (4) Using a voltmeter, connect the positive (+) tester probe to terminal VG, and negative (-) tester probe to terminal E2G.
- (5) Blow air into the air flow meter, and check that the voltage fluctuates.

If operation is not as specified, replace the air flow meter.

- (6) Turn the ignition switch OFF.
- (7) Disconnect the negative (-) terminal cable from the battery.
- (8) Disconnect the air flow meter connector.

4. **REINSTALL AIR FLOW METER**

Install the air flow meter with the 2 screws.

5. **RECONNECT AIR FLOW METER CONNECTOR**