



INSPECTION

1. INSPECT HEATER RESISTANCE OF OXYGEN SENSORS

- Disconnect the oxygen sensor connector.
- Using an ohmmeter, measure the resistance between terminals +B and HT.

Resistance: 11 – 16 Ω at 20 °C (68 °F)

If the resistance is not as specified, replace the sensor.

Torque:

44 N·m (450 kgf·cm, 32 ft·lbf) for sensor 1

20 N·m (200 kgf·cm, 14 ft·lbf) for sensor 2

- Reconnect the oxygen sensor connector.
- ### 2. INSPECT OPERATION OF OXYGEN SENSORS (See [page DI-51](#))