

DTC	C 1203 / 53	Engine and ECT ECU Communication Circuit Malfunction
------------	--------------------	---

CIRCUIT DESCRIPTION


The circuit is used to send TRC & VSC control information from the ABS & BA & TRC & VSC ECU to the engine and ECT ECU (TRC+, TRC -), and engine control information from the engine and ECT ECU to the ABS & BA & TRC & VSC ECU (ENG+, ENG -).

DTC No.	DTC Detecting Condition	Trouble Area
C1203/53	Either of the following 1. or 2. continues for 5 sec.: 1. ECU IG 1 terminal voltage is 9.5V to 17.0V and data transmission to the engine and ECT ECU is impossible. 2. ECU IG 1 terminal voltage is 9.5V to 17.0V, engine speed is 500 rpm or more or vehicle speed is 60 km/h (36 mph) or more and data receiving from the engine and ECT ECU is impossible.	<ul style="list-style-type: none"> • TRC+ or TRC - circuit • ENG+ or ENG - circuit • Engine and ECT ECU

Fail safe function:

If trouble occurs in the engine and ECT ECU communication circuit, the ECU prohibits TRC & VSC control.


WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check ABS & BA & TRC & VSC ECU communication.

(REFERENCE) INSPECTION USING OSCILLOSCOPE



PREPARATION:

- (a) Remove the ABS & BA & TRC & VSC ECU.
- (b) Connect the oscilloscope to the each of terminals ENG+ or TRC+ and GND of the ABS & BA & TRC & VSC ECU.

CHECK:

Start the engine, and check the signal waveform.

NG

Check and replace ABS & BA & TRC & VSC ECU.

OK

2 Check for open and short circuit in harness and connector between each of terminals ENG+, ENG -, TRC+, TRC - of ABS & BA & TRC & VSC ECU and engine and ECT ECU (See page IN-35).

NG

Repair or replace harness or connector.

OK

Check and replace engine and ECT ECU.