

TROUBLESHOOTING

PROBLEM SYMPTOMS TABLE

BE1ZX-01

HEADLIGHT AND TAILLIGHT SYSTEM:

This system uses the multiplex communication system, so check diagnosis system of the multiplex communication system before you proceed with troubleshooting.

HINT:

To inspect the bulb and light control ECU, replace them with the ones working normally and judge whether they work normally or not.

Symptom	Suspect Area	See page
Only one headlight comes on.	1. Bulb ¹ 2. * Light Control ECU 3. Wire Harness	- - -
"LO-Beam" does not light (All).	1. Headlight Control Relay ¹ 2. * Light Control ECU 3. Wire Harness	BE-3 - -
"LO-Beam" does not light (One side).	1. Bulb 2. H ₁ -LPL-LWRFuse 3. H ₁ -LPR-LWRFuse 4. * Light Control ECU 5. Wire Harness	- * ² BE-14 * ² BE-14 - -

*¹: HID Type

*²: See Pub. No. RM616E on page