


CIRCUIT INSPECTION

Tc Terminal Circuit

CIRCUIT DESCRIPTION


Connecting terminals Tc and E₁ of the check connector or Tc and CG of DLC3 causes the ECU to display the DTC by flashing the ABS warning light.

WIRING DIAGRAM



INSPECTION PROCEDURE

- | | |
|---|--|
| 1 | Check voltage between terminals Tc and E₁ of check connector or Tc and CG of DLC3. |
|---|--|

**PREPARATION:**

Turn the ignition switch ON.

CHECK:

Measure voltage between terminal Tc and E₁ of check connector or Tc and CG of DLC3.

OK:

Voltage: 10 – 14 V

OK

If ABS warning light does not blink even after Tc and E₁ of check connector or Tc and CG of DLC3 are connected, the ECU may be defective.

NG

- | | |
|---|--|
| 2 | Ignition switch OFF, and check for open and short circuit in harness and connector between ABS ECU and check connector or DLC3, check connector or DLC3 and body ground (See page IN-35). |
|---|--|

NG

Repair or replace harness or connector.

OK

Check and replace ABS ECU.