


DTC	RrACSW, FACE	Rear Room Temperature Sensor Circuit
-----	--------------	--------------------------------------

CIRCUIT DESCRIPTION

This sensor detects the temperature inside the cabin and sends the appropriate signals to the rear A/C amplifier.

Blinking light	Detection Item	Trouble Area
RrACSW, FACE	Open or short in rear room temperature sensor circuit.	<ul style="list-style-type: none">•Rear room temperature sensor.•Harness or connector between rear room temperature sensor and rear A/C amplifier.•Rear A/C amplifier.


WIRING DIAGRAM



I08282

INSPECTION PROCEDURE

1	Check voltage between terminals TRr and SG2 of A/C amplifier connector.
----------	--

**PREPARATION:**

Remove rear A/C amplifier with connectors still connected.

CHECK:

- (a) Turn ignition switch to ON.
- (b) Measure voltage between terminals TRr and SG2 of rear A/C amplifier connector at each temperature.

OK:**Voltage :**

at 25° C (77° F) : 1.8 – 2.2 V

at 40° C (104° F) : 1.2 – 1.6 V

HINT:

As the temperature increases, the voltage decreases.


NG

Go to step 3.

OK

Proceed to next circuit inspection shown on problem symptoms table ([See page DI-130](#)). However, if RrACSW and FACE indicators light up (or DTC 19 is displayed), check and replace A/C amplifier.

2	Check rear room temperature sensor.
----------	--

**PREPARATION:**

Disconnect rear room temperature sensor connector.

CHECK:

Measure resistance between terminals 1 and 2 of room temperature sensor connector at each temperature.

OK:**Resistance :**

at 25° C (77° F) : 1.65 – 1.75 k Ω

at 50° C (122° F) : 0.55 – 0.65 k Ω

HINT:

As the temperature increases, the resistance decreases.

NG

Replace rear room temperature sensor.

OK

3**Check harness and connector between rear A/C amplifier and rear room temperature sensor ([See page IN-34](#)).****NG****Repair or replace harness or connector.****OK****Check and replace A/C amplifier.**