


DTC	RrACSW, HI	Rear Inlet Air Temperature Sensor Circuit
------------	-------------------	--

CIRCUIT DESCRIPTION


This sensor detects the rear inlet air temperature and sends the appropriate signals to the A/C amplifier.

Blinking light	Detection Item	Trouble Area
RrACSW, HI	Open or short in rear inlet air temperature sensor circuit.	<ul style="list-style-type: none"> • Rear inlet air temperature sensor • Harness or connector between rear inlet air temperature sensor and rear A/C amplifier • Rear A/C amplifier

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check voltage between terminals Tinr and SG1 of rear A/C amplifier connector.**PREPARATION:**

Remove rear A/C amplifier with connectors still connected.

CHECK:

- Turn ignition switch to ON.
- Measure voltage between terminals Tinr and SG1 of rear A/C amplifier connector at each temperature.

OK:**Voltage :**

at 25° C (77° F) : 1.8 – 2.2 V


at 40° C (104° F) : 1.2 – 1.6 V

HINT:

As the temperature increases, the voltage decreases.

NG**Go to step 2.****OK**

Proceed to next circuit inspection shown on problem symptoms table (See page DI-130). However, if RrACSW and HI indicators light up (or DTC 26 is displayed), check and replace rear A/C amplifier.

2 Check rear inlet air temperature sensor.**PREPARATION:**

Disconnect rear inlet air temperature sensor connector.

CHECK:

Measure resistance between terminals 1 and 2 of rear inlet air temperature sensor connector at each temperature.

OK:**Resistance :**

at 25° C (77° F) : 1.65 – 1.75 k Ω

at 50° C (122° F) : 0.55 – 0.65 k Ω

HINT:

As the temperature increases, the resistance decreases.

NG**Replace rear inlet air temperature sensor.****OK**

3**Check harness and connector between rear A/C amplifier and inlet air temperature sensor ([See page IN-34](#)).****NG****Repair or replace harness or connector.****OK****Check and replace rear A/C amplifier.**