

DIAGNOSTIC TROUBLE CODE CHART

HINT:

Parameters listed in the chart may not be exactly the same as you reading due to the type of instrument or other factors.

If a malfunction code is displayed during the DTC check in check(test) mode, check the circuit for that code listed in the table below. For details of each code, turn to the page referred to under the "See Page" for the respective "DTC No." in the DTC chart.

DTC No. (See Page)	Detection Item	Trouble Area	*1 Check Engine Warning Light (Normal Mode/ Test Mode)	*2 Memory
12 (□)	Crankshaft Position Sensor Circuit Malfunction	<ul style="list-style-type: none"> • Open or short in crankshaft position sensor circuit • Crankshaft position sensor • Engine ECU 	ON/ON	□
13 (□)	Engine Speed Sensor Circuit Malfunction	<ul style="list-style-type: none"> • Open or short in engine speed sensor circuit • Engine speed sensor • Open or short in STA circuit • Engine ECU 	ON/ON	□
14 (□)	Timing Control System Malfunction	<ul style="list-style-type: none"> • Open or short in timing control valve circuit • Fuel filter (Clogging) • Fuel (Freezing, Air in) • Injection pump (Internal pressure and timing control valve) • Engine ECU 	ON/N.A.	□
15 (DI-23)	Throttle Control Motor Circuit Malfunction	<ul style="list-style-type: none"> • Open or short in throttle control motor circuit • Throttle control motor • Throttle valve • Engine ECU 	ON/N.A.	□
17 (□)	Interior IC Malfunction	<ul style="list-style-type: none"> • Engine ECU 	ON/N.A.	□
19(1) (□)	Accelerator Pedal Position Sensor Circuit Malfunction (Open/Short)	<ul style="list-style-type: none"> • Open or short in accelerator pedal position sensor circuit • Accelerator pedal position sensor • Engine ECU 	ON/ON	□
19(2) (□)	Accelerator Pedal Position Sensor Circuit Malfunction (IDL Switch / Range)	<ul style="list-style-type: none"> • Open or short in accelerator pedal position sensor circuit • Accelerator pedal position sensor • Engine ECU 	ON/ON	□
19(3) (□)	Accelerator Pedal Closed Posi- tion Switch Circuit Malfunction (Short)	<ul style="list-style-type: none"> • Short in accelerator pedal closed position switch circuit • Accelerator pedal closed position switch • Engine ECU 	ON/ON	□
19(4) (□)	Accelerator Pedal Closed Posi- tion Switch Circuit Malfunction (Open)	<ul style="list-style-type: none"> • Open in accelerator pedal closed position switch circuit • Accelerator pedal closed position switch • Engine ECU 	ON/ON	□
22 (□)	Water Temp. Sensor Circuit Malfunction	<ul style="list-style-type: none"> • Open or short in water temp. sensor circuit • Water temp. sensor • Engine ECU 	ON/ON	□
24(1) (□)	Intake Air Temp. Sensor Circuit Malfunction	<ul style="list-style-type: none"> • Open or short in intake air temp. sensor circuit • Intake air temp. sensor • Engine ECU 	OFF/ON	□
24(2) (DI-26)	Atmospheric Temp. Sensor Cir- cuit Malfunction	<ul style="list-style-type: none"> • Open or short in intake air temp. sensor circuit • Atmospheric temp. sensor (built into air flow meter) • Engine ECU 	OFF/ON	□

DTC No. (See Page)	Detection Item	Trouble Area	*1 Check Engine Warning Light (Normal Mode/ Test Mode)	*2 Memory
31 (DI-31)	Air Flow Circuit Malfunction	<ul style="list-style-type: none"> • Open or short in air flow meter circuit • Air flow meter • Engine ECU 	ON/N.A.	<input type="checkbox"/>
32 (□)	Injection Pump System Malfunction	<ul style="list-style-type: none"> • Open or short in injection pump correction unit circuit • Injection pump correction unit • Engine ECU 	OFF/N.A.	<input type="checkbox"/>
34 (2) (DI-38)	Turbocharger system malfunction	<ul style="list-style-type: none"> • Turbocharger • EGR valve • Air flow meter • Engine ECU 	ON/N.A.	<input type="checkbox"/>
34 (3) (DI-38)	Turbocharger stick detected (Close)	<ul style="list-style-type: none"> • Turbocharger • EGR valve • Air flow meter • Engine ECU 	ON/N.A.	<input type="checkbox"/>
34 (4) (DI-38)	Turbocharger stick detected (Open)	<ul style="list-style-type: none"> • Turbocharger • EGR valve • Air flow meter • Engine ECU 	ON/N.A.	<input type="checkbox"/>
35 (□)	Turbo Pressure Sensor Circuit Malfunction	<ul style="list-style-type: none"> • Open or short in turbo pressure sensor circuit • Turbo pressure sensor • Engine ECU 	ON/ON	<input type="checkbox"/>
39 (□)	Fuel Temp. Sensor Circuit Malfunction	<ul style="list-style-type: none"> • Open or short in fuel temp. sensor circuit • Fuel pressure sensor • Engine ECU 	ON/ON	<input type="checkbox"/>
42 (□)	Vehicle Speed Sensor Signal Circuit Malfunction	<ul style="list-style-type: none"> • Open or short in vehicle speed sensor circuit • Vehicle speed sensor • Combination meter • Engine ECU 	OFF/ON	<input type="checkbox"/>
58 (DI-45)	SCV stick detected (closed)	<ul style="list-style-type: none"> • Turbocharger • EGR valve • Air flow meter • Engine ECU 	ON/ON	<input type="checkbox"/>
89	Interior IC Malfunction	<ul style="list-style-type: none"> • Engine ECU 	ON/N.A.	<input type="checkbox"/>
97 (□)	EDU Circuit Malfunction	<ul style="list-style-type: none"> • Open or short in EDU circuit • Spill control valve • EDU 	ON/N.A.	<input type="checkbox"/>
*3 99	Engine Immobilizer System Malfunction	<ul style="list-style-type: none"> • Open or short in engine immobilizer system circuit • Transponder key amplifier • Transponder key computer • Transponder key coil • Engine ECU 	OFF/ON	<input type="checkbox"/>

*1: "ON" displayed in the diagnosis mode column indicates that the check engine warning light is lighted up when a malfunction is detected. "OFF" indicates that the "CHECK ENGINE" does not light up during malfunction diagnosis, even if a malfunction is detected. "N.A." indicates that the item is not included in malfunction diagnosis.

*2: " ☐ " in the memory column indicates that a diagnostic trouble code is recorded in the engine ECU memory when a malfunction occurs. Accordingly, output of diagnostic results in normal or test mode is done with the IG switch ON.

*3: See Pub. No. RM616E BE section.

☐ : See Pub. No. RM617E