



## REMOVAL

### REMOVE DRIVE BELT

- (a) Loosen the idle pulley lock nut.
- (b) Loosen the drive belt by adjusting bolt and remove the drive belt.