

INSTALLATION

Installation is in the reverse order of removal ([See page AC-25](#)).

HINT:

w/ Navigation System:

When removing/installing or replacing EMV, or when disconnecting/connecting the battery terminal, turn the IG ON and OFF twice for initial display setting.