

<b>DTC</b>	<b>P0976/63</b>	<b>Shift Solenoid "B" Control Circuit Low (Shift Solenoid Valve S2)</b>
------------	-----------------	---


<b>DTC</b>	<b>P0977/63</b>	<b>Shift Solenoid "B" Control Circuit High (Shift Solenoid Valve S2)</b>
------------	-----------------	--

## CIRCUIT DESCRIPTION

See page DI-49.


DTC No.	DTC Detection Condition	Trouble Area
P0976/63	Engine and ECT ECU detects short in solenoid valve S2 circuit 4 times when solenoid valve S2 is operated (1 –trip detection logic)	<ul style="list-style-type: none"> <li>• Short in shift solenoid valve S2 circuit</li> <li>• Shift solenoid valve S2</li> <li>• Engine and ECT ECU</li> </ul>
P0977/63	Engine and ECT ECU detects open in solenoid valve S2 circuit 4 times when solenoid valve S2 is not operated (1 –trip detection logic)	<ul style="list-style-type: none"> <li>• Open in shift solenoid valve S2 circuit</li> <li>• Shift solenoid valve S2</li> <li>• Engine and ECT ECU</li> </ul>

## WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 Check transmission wire.

**PREPARATION:**

Disconnect the transmission wire connector.

**CHECK:**

Measure resistance between S2 of transmission wire connector and body ground.

**OK:**


**Resistance: 11 – 15  $\Omega$  at 20° C (68° F)**

NG

Go to step 3.

OK

## 2 Measure resistance between terminal S2 and E1 of Engine and ECT ECU connector.

**PREPARATION:**

(a) Connect the transmission wire connector.

(b) Disconnect the connector of the Engine and ECT ECU.

**CHECK:**

Measure resistance between terminals S2 and E1 of Engine and ECT ECU connector.

**OK:**

**Resistance: 11 – 15  $\Omega$  at 20° C (68° F)**


NG

**Repair or replace the harness or connector**  
(See page IN-38).

OK

**Check and replace the Engine and ECT ECU**  
(See page IN-38).

### 3 Check shift solenoid valve S2.

**PREPARATION:**

- (a) Jack up the vehicle.
- (b) Remove the oil pan.
- (c) Remove the shift solenoid valve S2.

**CHECK:**

Measure the resistance between the solenoid connector terminal and the body ground.

**OK:**

**Resistance: 11 – 15  $\Omega$  at 20° C (68° F)**

**CHECK:**

Connect the battery positive lead to the solenoid connector terminal and the battery negative lead to the solenoid body ground.

**OK:**

**Solenoid sounds operation noise.**

**NG**

**Replace the shift solenoid valve S2**  
(See page AT-8).

**OK**

**Repair or replace the transmission wire**  
(See page AT-6).