


DTC	62( 1)	Shift Solenoid A Electrical (S 1)
-----	--------	-----------------------------------

CIRCUIT DESCRIPTION

See page DI-135.


DTC No.	DTC Detecting Condition	Trouble Area
62(1)	<p>The Engine &amp; ECT ECU checks for an open or short circuit in the shift solenoid valve S1 circuit when it changes. (1 –trip detection logic)</p> <p>The Engine &amp; ECT ECU records DTC 62(1) if condition (a) or (b) is detected once, but it does not light up check engine warning light.</p> <p>After Engine &amp; ECT ECU detects condition (a) or (b) continuously 8 times or more in one –trip, it causes the check engine warning light light up until condition (a) or (b) disappears.</p> <p>After that, if the Engine &amp; ECT ECU detects condition (a) or (b) once, it starts lighting up check engine warning light again.</p> <p>(a) Solenoid resistance is 8 Ω or less (short circuit) when the solenoid is energized.</p> <p>(b) Solenoid resistance is 100 k Ω or more (open circuit) when the solenoid is not energized.</p>	<ul style="list-style-type: none"><li>• Open or short in shift solenoid valve S1 circuit</li><li>• Shift solenoid valve S1</li><li>• Engine and ECT ECU</li></ul>

WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 Check transmission wire.

**PREPARATION:**

Disconnect the transmission wire connector.

**CHECK:**

Measure resistance between S1 of transmission wire connector and body ground.

**OK:**


**Resistance: 11 – 15  $\Omega$  at 20° C (68° F)**

NG

Go to step 3.

OK

## 2 Measure resistance between terminal S1 and E1 of Engine and ECT ECU connector.

**PREPARATION:**

- (a) Connect the transmission wire connector.
- (b) Disconnect the connector of the Engine and ECT ECU.

**CHECK:**

Measure resistance between terminals S1 and E1 of Engine and ECT ECU connector.

**OK:**

**Resistance: 11 – 15  $\Omega$  at 20° C (68° F)**


NG

**Repair or replace the harness or connector**  
(See page IN-38).

OK

**Check and replace the Engine and ECT ECU**  
(See page IN-38).

### 3 Check shift solenoid valve S1.

**PREPARATION:**

- (a) Jack up the vehicle.
- (b) Remove the oil pan.
- (c) Remove the shift solenoid valve S1.

**CHECK:**

Measure the resistance between the solenoid connector terminal and the body ground.

**OK:**

**Resistance: 11 – 15  $\Omega$  at 20° C (68° F)**

**CHECK:**

Connect the battery positive lead to the solenoid connector terminal and the battery negative lead to the solenoid body ground.

**OK:**

**Solenoid sounds operation noise.**

**NG**

**Replace the shift solenoid valve S1**  
(See page AT-8).

**OK**

**Repair or replace the transmission wire**  
(See page AT-6).