

## Shift Solenoid Malfunction

### SYSTEM DESCRIPTION


See page DI-135.

HINT:

- Start the inspection from step 1 when shift solenoid valve SL1.
- Start the inspection from step 2 when shift solenoid valve SL2.
- Start the inspection from step 3 when shift solenoid valve SLT.
- Start the inspection from step 4 when shift solenoid valve SLU.
- Start the inspection from step 5 when shift solenoid valve S1.
- Start the inspection from step 5 when shift solenoid valve S2.
- Start the inspection from step 6 when shift solenoid valve SR.

### INSPECTION PROCEDURE

#### 1 Check shift solenoid valve SL1 operation.



D12795

#### PREPARATION:

Remove the shift solenoid valve SL1.

#### CHECK:

- (a) Measure the resistance between terminals 1 and 2 of solenoid connector.

**Standard: 5.0 – 5.6  $\Omega$  at 20° C (68° F)**

- (b) Connect the positive (+) lead with an 21 W bulb to terminal 2 of solenoid connector and negative (–) lead to terminal 1 of the solenoid valve connector, then check the movement of the valve.

**Standard: Solenoid sounds operation noise.**

#### OK:

Standard


OK

Go to step 7.

NG

Replace shift solenoid valve SL 1  
(See page AT-8).

## 2 Check shift solenoid valve SL2 operation.



D12795

### PREPARATION:

- Jack up the vehicle.
- Remove the oil pan.
- Remove the shift solenoid valve SL2.

### CHECK:

- Measure the resistance between terminals 1 and 2 of solenoid connector.

**Standard: 5.0 – 5.6  $\Omega$  at 20° C (68° F)**

- Connect the positive (+) lead with an 21 W bulb to terminal 2 of solenoid connector and negative (-) lead to terminal 1 of the solenoid valve connector, then check the movement of the valve.

**Standard: Solenoid sounds operation noise.**

### OK:


**Standard**

**OK**

**Go to step 7.**

**NG**

**Replace shift solenoid valve SL2**  
(See page AT-8).

**3 Check shift solenoid valve SLT operation.**

P

D11987

**PREPARATION:**

- (a) Jack up the vehicle.
- (b) Remove the oil pan.
- (c) Remove the shift solenoid valve SLT.

**CHECK:**

- (a) Measure the resistance between terminals 1 and 2 of solenoid connector.


**Standard: 5.0 – 5.6  $\Omega$  at 20° C (68° F)**

- (b) Connect the positive (+) lead with an 21 W bulb to terminal 2 of solenoid connector and negative (–) lead to terminal 1 of the solenoid valve connector, then check the movement of the valve.

**Standard: Solenoid sounds operation noise.****OK:****Standard****OK****Go to step 7.****NG**

**Replace shift solenoid valve SLT**  
 (See page AT-8).

#### 4 Check shift solenoid valve SLU operation.



D12795

#### PREPARATION:

- Jack up the vehicle.
- Remove the oil pan.
- Remove the shift solenoid valve SLU.

#### CHECK:

- Measure the resistance between terminals 1 and 2 of solenoid connector.

**Standard: 5.0 – 5.6 Ω at 20° C (68° F)**

- Connect the positive (+) lead with an 21 W bulb to terminal 2 of solenoid connector and negative (–) lead to terminal 1 of the solenoid valve connector, then check the movement of the valve.

**Standard: Solenoid sounds operation noise.**

#### OK:



**Standard**

**OK**

**Go to step 7.**

**NG**

**Replace shift solenoid valve SLU**  
(See page AT-8).

**5 Check shift solenoid valve S1 or S2 operation.**
**Shift solenoid S1:**

**Shift solenoid S2:**

D11991  
D11992

D13058

**PREPARATION:**

- Jack up the vehicle.
- Remove the oil pan.
- Remove the shift solenoid valve S1 or S2.

**CHECK:**

Measure the resistance between the solenoid connector terminal and the body ground.

**OK:**

Resistance: 11 – 15  $\Omega$  at 20°C (68°F)

**CHECK:**

Connect the battery positive lead to the solenoid connector terminal and the battery negative lead to the solenoid body ground.


**OK:**

Solenoid sounds operation noise.

**OK**
**Go to step 7.**
**NG**

Replace shift solenoid valve S1 or S2  
(See page AT-8).

## 6 Check shift solenoid valve SR operation.



### PREPARATION:

- Jack up the vehicle.
- Remove the oil pan.
- Remove the shift solenoid valve SR.

### CHECK:

Measure the resistance between the solenoid connector terminal and the body ground.

### OK:

Resistance: 11 – 15  $\Omega$  at 20°C (68°F)

### CHECK:

Connect the battery positive lead to the solenoid connector terminal and the battery negative lead to the solenoid body ground.

### OK:

Solenoid sounds operation noise.

OK

Go to step 7.

NG

Replace shift solenoid valve SR  
(See page AT-8).

## 7 Check valve body.

NG

Repair or replace valve body  
(See page AT-8).

OK

Proceed to next circuit inspection shown on  
problem symptoms table  
(See page DI-119).