

DIAGNOSTIC TROUBLE CODE CHART

NOTICE:

When removing the part, turn the ignition switch OFF.

HINT:

- Using SST 09843-18020, connect the terminals Tc and E₁ of check connector.
- If any abnormality is not found when inspecting parts, inspect the ECU.
- If a malfunction code is displayed during the DTC check, check the circuit listed that code. For details of each code, turn to the page referred to under the "See page" for respective "DTC No." in the DTC chart.

DTC chart of ABS:

| DTC No. (See Page) | Detection Item | Trouble Area |
|------------------------|---|---|
| C0278 / 11 (DI-218) | Open or short circuit in ABS solenoid relay circuit | • ABS solenoid relay • ABS solenoid relay circuit |
| C0279 / 12 (DI-218) | B+ short circuit in ABS solenoid relay circuit | |
| C0226/21 (DI-215) | Open or short circuit in hydraulic brake booster solenoid circuit (SFR circuit) | • Hydraulic brake booster • SFR or SFRH circuit |
| C0236/22 (DI-215) | Open or short circuit in hydraulic brake booster solenoid circuit (SFL circuit) | • Hydraulic brake booster • SFL or SFLH circuit |
| C0246/23 (DI-215) | Open or short circuit in hydraulic brake booster solenoid circuit (SRR circuit) | • Hydraulic brake booster • SRR or SRRH circuit |
| C0256/24 (DI-215) | Open or short circuit in hydraulic brake booster solenoid circuit (SRL circuit) | • Hydraulic brake booster • SRL or SRLH circuit |
| C1225/25 (DI-233) | Open or short circuit in hydraulic brake booster solenoid circuit (SA1 circuit) | • Hydraulic brake booster • SA1 circuit |
| C1226/26 (DI-233) | Open or short circuit in hydraulic brake booster solenoid circuit (SA2 circuit) | • Hydraulic brake booster • SA2 circuit |
| C1227/27 (DI-233) | Open or short circuit in hydraulic brake booster solenoid circuit (SA3 circuit) | • Hydraulic brake booster • SA3 circuit |
| C1228/28 (DI-233) | Open or short circuit in hydraulic brake booster solenoid circuit (STR circuit) | • Hydraulic brake booster • STR circuit |
| C0200/31* (DI-208) | Right front wheel speed sensor signal malfunction | |
| C0205/32* (DI-208) | Left front wheel speed sensor signal malfunction | • Right front, left front, right rear and left rear speed sensor • Each speed sensor circuit • Sensor rotor |
| C0210/33* (DI-208) | Right rear wheel speed sensor signal malfunction | |
| C0215/34* (DI-208) | Left rear wheel speed sensor signal malfunction | |
| C1235 / 35 (DI-208) | Foreign matter is attached on the tip of the right front sensor | • Right front, left front, right rear, left rear speed sensor • Speed sensor rotor |
| C1236 / 36 (DI-208) | Foreign matter is attached on the tip of the left front sensor | |
| C1237 / 37 (DI-247) | Some tire is different size from the other tires | Tire size |
| C1238 / 38 (DI-208) | Foreign matter is attached on the tip of the right rear sensor | • Right front, left front, right rear, left rear speed sensor • Speed sensor rotor |
| C1239 / 39 (DI-208) | Foreign matter is attached on the tip of the left rear sensor | |

| | | |
|--------------------------------------|---|--|
| C1241 / 41 (DI-248) | Low battery voltage or abnormally high battery voltage | <ul style="list-style-type: none"> • Battery • IC regulator • Power source circuit |
| C1242 / 42* ² (DI-251) | Open circuit in IG2 circuit | <ul style="list-style-type: none"> • Battery • IC regulator • Power source circuit |
| C1243 / 43 (DI-254) | Malfunction in deceleration sensor (constant output) | <ul style="list-style-type: none"> • Deceleration sensor • Wire harness for deceleration sensor system |
| C1244 / 44 (DI-258) | Open or short circuit in deceleration sensor circuit | <ul style="list-style-type: none"> • Deceleration sensor • Deceleration sensor circuit |
| C1245 / 45 (DI-254) | Malfunction in deceleration sensor | <ul style="list-style-type: none"> • Deceleration sensor • Wire harness for deceleration sensor system |
| C1246 / 46 (DI-261) | Malfunction in master cylinder pressure sensor | <ul style="list-style-type: none"> • Master cylinder pressure sensor • Master cylinder pressure sensor circuit |
| C1249 / 49 (DI-264) | Open circuit in stop light switch circuit | Stop light switch circuit |
| C1251 / 51* ² (DI-268) | Pump motor is locked Open circuit in pump motor ground | Hydraulic brake booster pump motor |
| C1252 / 52* ² (DI-271) | Hydraulic brake booster pump motor malfunction | <ul style="list-style-type: none"> • Hydraulic brake booster pump motor • Hydraulic brake booster pump motor circuit • Pressure switch (PH or PL) |
| C1253 / 53* ² (DI-277) | Hydraulic brake booster pump motor relay malfunction | <ul style="list-style-type: none"> • ABS motor 1 or ABS motor 2 relay • ABS motor 1 or ABS motor 2 relay circuit • Hydraulic brake booster pump motor circuit |
| C1254 / 54* ² (DI-282) | Pressure switch malfunction | <ul style="list-style-type: none"> • Pressure switch (PH or PL) • Pressure switch circuit |
| C1256 / 56* ² (DI-285) | Accumulator low pressure malfunction | <ul style="list-style-type: none"> • Accumulator • Pressure switch (PH or PL) • Hydraulic brake booster pump motor |
| C1257 / 57* ² (DI-291) | Power supply drive circuit malfunction | <ul style="list-style-type: none"> • Battery • Power source circuit • Skid control ECU |
| C1203 / 59 (DI-225) | Engine and ECT ECU communication circuit malfunction | <ul style="list-style-type: none"> • TRC+ or TRC- circuit • ENG+ or ENG- circuit • Engine and ECT ECU |
| C1268 / 68 (DI-294) | Transfer L4 position signal transmission failure | <ul style="list-style-type: none"> • Transfer L4 position switch • Transfer L4 position switch circuit |
| Always ON (DI-307) | Malfunction in skid control ECU | <ul style="list-style-type: none"> • Battery • IC regulator • Power source circuit • Skid control ECU |

* : As the DTC cannot be erased by replacing parts alone do either of the following operations.

Clear DTC (See page DI-185).

At the vehicle speed of 20 km/h (12 mph), drive the vehicle for 30 sec. or more.

*² : Using the following table, troubled parts can be specified.

| DTC | | 42 | | 51 | | 52 | | 53 | | 54 | | 56 | | 57 | |
|--------------------------------|----------------------|-------|--------|-------|--------|-------|--------|-------|--------|-------|--------|-------|--------|-------|--------|
| BRAKE warning light and buzzer | | Light | Buzzer |
| Pressure switch | PH | | | | | □ | □ | | | □ | | □ | □ | | |
| | PL | | | | | □ | □ | | | □ | | □ | □ | | |
| Pump motor circuit | Pump motor | | | □ | □ | □ | □ | | | | | □ | □ | | |
| | MTT wire harness | | | | | | | | | | | | | | |
| | MT+ wire harness | | | □ | | | | | | | | | | | |
| | MT- wire harness | | | □ | | | | | | | | | | | |
| Accumulator malfunction | | | | | | | | | | | | □ | □ | | |
| Motor relay circuit | MR1 open circuit | | | | | | | □ | | | | | | | |
| | MR2 open circuit | | | | | | | □ | | | | | | | |
| | MR1 welded contact | | | | | □ | □ | □ | | | | | | | |
| | MR2 welded contact | | | | | □ | □ | □ | | | | | | | |
| Hydraulic brake booster | Pressure leaks | | | | | □ | □ | | | | | □ | □ | | |
| Power source* | IG2 open circuit | □ | | | | | | | | | | | | | |
| ECU | Power supply circuit | | | | | | | | | | | | □ | | |

*: When IG1 circuit is open, ABS warning light and BRAKE warning light come on.

DTC chart of VSC:

| DTC No. (See Page) | Detection Item | Trouble Area |
|-------------------------|--|--|
| C1231 / 31 (DI-236) | Malfunction in steering angle sensor | <ul style="list-style-type: none"> • Steering angle sensor • Steering angle sensor circuit |
| C1232 / 32 (DI-241) | Malfunction in deceleration sensor | <ul style="list-style-type: none"> • Deceleration sensor • Deceleration sensor circuit |
| C1233 / 33 (DI-244) | Open or short circuit in yaw rate sensor circuit | <ul style="list-style-type: none"> • Yaw rate sensor • Yaw rate sensor circuit |
| C1234 / 34 (DI-244) | Malfunction in yaw rate sensor | <ul style="list-style-type: none"> • Yaw rate sensor • Yaw rate sensor circuit |
| C1335 / 35 (DI-236) | Malfunction in steering angle sensor communication circuit | <ul style="list-style-type: none"> • Steering angle sensor • Steering angle sensor circuit |
| C1210 / 36 (DI-300) | Zero point calibration of yaw rate sensor undone | <ul style="list-style-type: none"> • Yaw rate sensor • Yaw rate sensor circuit • Neutral start switch circuit (P range) |
| C1336 / 39 (DI-300) | Zero point calibration of deceleration sensor | <ul style="list-style-type: none"> • Deceleration sensor • Deceleration sensor circuit • Neutral start switch (P range) circuit |
| C1289 / 41* (DI-230) | Malfunction in VGRS control system | VGRS control system |
| C1223 / 43 (DI-230) | Malfunction in ABS control system | ABS control system |
| C1224 / 44 (DI-231) | Open or short circuit in NE signal circuit | <ul style="list-style-type: none"> • NEO circuit • Engine and ECT ECU • Skid control ECU |
| C1340 / 47 (DI-303) | Open circuit in center differential lock signal | <ul style="list-style-type: none"> • Center differential lock system • Center differential lock circuit |
| C1291 / 48* (DI-225) | VGRS ECU communication circuit malfunction | <ul style="list-style-type: none"> • VSC+ or VSC – circuit • AFS+ or AFS – circuit • Engine and ECT ECU |
| C1201 / 51 (DI-224) | Engine and ECT ECU system malfunction | Engine control system |
| C1203 / 53 (DI-225) | Engine and ECT ECU communication circuit malfunction | <ul style="list-style-type: none"> • TRC+ or TRC – circuit • ENG+ or ENG – circuit • Engine and ECT ECU |
| Always ON (DI-310) | Malfunction in skid control ECU Open circuit in VSC TRC warning light circuit | <ul style="list-style-type: none"> • Power source circuit • VSC TRC warning light circuit |

*: w/ VGRS only

HINT:

There is a case that hand –held tester cannot be used when VSC TRC warning light is always on.