

PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

NOTICE:

When replacing skid control ECU, sensor or etc., turn the ignition switch OFF.

Symptom	Suspect Area	See page
ABS does not operate. BA does not operate.	Only when 1. to 4. are all normal and the problem is still occurring, replace the skid control ECU. 1. Reconfirm the DTC and check that the normal code is output. 2. IG power source circuit 3. Speed sensor circuit 4. Check the hydraulic brake booster with a checker or hand-held tester. If abnormal, check the hydraulic circuit for leakage (See page DI-343).	DI-185 DI-248 DI-208 -
ABS does not operate efficiently. BA does not operate.	Only when 1. to 4. are all normal and the problem is still occurring, replace the skid control ECU. 1. Reconfirm the DTC and check that the normal code is output. 2. Speed sensor circuit 3. Stop light switch circuit 4. Check the hydraulic brake booster with a checker or hand-held tester. If abnormal, check the hydraulic circuit for leakage (See page DI-343).	DI-185 DI-208 DI-264 -
ABS warning light abnormal.	1. ABS warning light circuit 2. Skid control ECU	DI-313 IN-38
DTC check cannot be done.	Only when 1. to 3. are all normal and the problem is still occurring, replace the skid control ECU. 1. ABS warning light circuit 2. VSC OFF indicator light, center diff. lock indicator switch circuit 3. Tc terminal circuit	DI-313 DI-332 DI-339
Speed sensor signal check cannot be done.	1. Ts terminal circuit 2. Skid control ECU	DI-341 IN-38
TRC does not operate.	Only when 1. to 4. are all normal and the problem is still occurring, replace the skid control ECU. 1. Check the DTC, reconfirming that the normal code is output. 2. IG power source circuit 3. Check the hydraulic circuit for leakage. 4. Speed sensor circuit	DI-185 DI-248 DI-343 DI-208
VSC does not operate.	Only when 1. to 7. are all normal and the problem is still occurring, replace the skid control ECU. 1. Check the DTC, reconfirming that the normal code is output. 2. IG power source circuit 3. Check the hydraulic circuit for leakage. 4. Speed sensor circuit 5. Deceleration sensor circuit 6. Yaw rate sensor circuit 7. Steering angle sensor circuit	DI-185 DI-251 DI-343 DI-208 DI-258 DI-244 DI-236
VSC TRC warning light abnormal.	1. VSC TRC warning light circuit 2. Skid control ECU	DI-317 IN-38

BRAKE warning light abnormal	1. BRAKE warning light circuit 2. Skid control ECU	DI-322 IN-38
SLIP indicator light abnormal.	1. SLIP indicator light circuit 2. Skid control ECU	DI-326 IN-38
VSC OFF indicator abnormal.	1. VSC OFF indicator light, center diff. lock switch circuit 2. Skid control ECU	DI-332 IN-38
ACTIVE TRC indicator light abnormal.	1. ACTIVE TRC indicator light circuit 2. Skid control ECU	DI-329 IN-38