


| | | |
|------------|-------------------|---|
| DTC | C1336 / 39 | Zero Point Calibration of Deceleration Sensor Undone |
|------------|-------------------|---|

CIRCUIT DESCRIPTION


| DTC No. | DTC Detecting Condition | Trouble Area |
|------------|---|--|
| C1236 / 39 | When any of following 1. through 2. is detected: 1. In TEST mode, the shift lever is shifted to other than P range with 2 sec. after ECU terminal IG1 is turned ON for the first time. 2. When the deceleration sensor zero point recorded in ECU is deleted. | <ul style="list-style-type: none"> • Deceleration sensor • Deceleration sensor circuit • Neutral start switch circuit (R range) |

WIRING DIAGRAM



INSPECTION PROCEDURE

| | |
|---|---|
| 1 | Perform zero point calibration of the yaw rate (deceleration) sensor (See page DI-185). |
|---|---|



2 Is DTC still output?


Check DTC on [page DI-185](#).

NO

End.

YES

3 Check yaw rate (deceleration) sensor.



PREPARATION:

- Connect 3 dry batteries of 1.5 V in series.
- Connect VYS terminal to the batteries' positive (+) terminal, and GYAW terminal to the batteries' negative (–) terminal. Apply about 4.5 V between VYS and GYAW terminals.

NOTICE:

Do not apply voltage of 6 V or more to terminals VYS and GYAW.

CHECK:

Check the output voltage of GL1 and GL2 terminals when the sensor is tilted forward and rearward.

OK:

| Symbols | Condition | Standard Value |
|---------|---------------|---------------------|
| GL1 | Horizontal | About 2.3 V |
| GL1 | Lean rearward | 1.0 V – about 2.3 V |
| GL1 | Lean forward | About 2.3 V – 3.5 V |
| GL2 | Horizontal | About 2.3 V |
| GL2 | Lean rearward | About 2.3 V – 3.5 V |
| GL2 | Lean forward | 1.0 V – about 2.3 V |

HINT:

- If the sensor is tilted too much it may show the wrong value.
- If dropped, the sensor should be replaced with a new one.
- The sensor removed from the vehicle should not be placed upside down.

NG

Replace yaw rate sensor.

OK

- | | |
|----------|---|
| 4 | Check for open or short circuit in harness and connector between yaw rate (deceleration) sensor and skid control ECU (See page IN-38). |
|----------|---|

NG

Repair or replace harness or connector.

OK

Check and replace skid control ECU.