


<b>DTC</b>	<b>C1527/27, C 1528/28</b>	<b>VGRS Actuator Malfunction</b>
------------	----------------------------	----------------------------------

## CIRCUIT DESCRIPTION

The VGRS ECU detects the actuator operation with the turning angle sensor. If a malfunction in the turning angle sensor is found, the VGRS ECU turns on the warning light and records the DTC.

DTC No.	DTC Detecting Condition	Trouble Area
C1527/27	The system detects that the difference between the actuator target angle and the actuator position is approx. 30 ° or more for 1 sec.	• VGRS actuator, • VGRS ECU
C1528/28	The system detects a momentary interruption of the motor rotating angle sensor signal (MSU, MSV and MSW) 10 times or an open circuit for 0.12 sec. minimum.	

## WIRING DIAGRAM



**INSPECTION PROCEDURE**

1	<b>Check MV wire for open circuit.</b>
---	--

**PREPARATION:**



Turn the ignition switch ON.

**CHECK:**

Check DTC (See page DI-348).

**OK:**

**DTCC 1561/61 is output**



2	<b>Observe the data for MTR REV ANG U, V, W on the hand –held tester.</b>
---	---

**HINT:**

Determine the trouble area by checking the motor revolution angle sensor signal with hand –held tester.  
When not using hand –held tester, go to step 3.

**PREPARATION:**

- (a) Connect the hand –held tester to DLC3.
- (b) Start the engine.
- (c) Using the hand –held tester, display the data list.

**CHECK:**

Check the motor revolution angle sensor signal when slowly turning the steering wheel referring to the data list.

**OK:**

**MTR REV ANG U: High or Low**

**MTR REV ANG V: High or Low**

**MTR REV ANG W: High or Low**

All OK	A
All NG	B
Others	C



**Proceed to step 3.**

**3 Check GND circuit of motor revolution angle sensor.**

**PREPARATION:**

Turn the ignition switch OFF.

**CHECK:**

Check continuity between terminal MG and GND of the VGRS ECU.

**OK:**

Continuity

NG

Replace VGRS ECU.

H F17325

OK



**4 Check motor revolution angle sensor signal.**

**PREPARATION:**

Disconnect the VGRS actuator connector.

**NOTICE:**

**Do not apply 12V to MV for more than 3 minutes.**



**CHECK:**

- Connect a jumper wire from Batt (+) to MV, and another jumper wire from body ground to LGND.
- Measure the resistance between terminals while slowly turning the steering wheel. The steering wheel must be turned a maximum of  $\pm 10^\circ$  from center.

**OK:**

Symbols (Terminals)	Resistance
MSW (2) – MGND (7)	
MSU (4) – MGND (7)	Below 1 k. $\Omega$ to above 100 k. $\Omega$
MSV (8) – MGND (7)	

NG

Replace VGRS actuator.

OK

**Replace the VGRS ECU.**

LAND CRUISER (W/G) SUP (RM970E)