

DTC	B0118/46	Short in Side Squib LH Circuit (to B+)
------------	-----------------	---

CIRCUIT DESCRIPTION

The side squib LH circuit consists of the airbag sensor assembly and the side airbag assembly LH. It causes the SRS to deploy when the SRS deployment conditions are satisfied.

For details of the function of each component, see OPERATION on [page RS-3](#).

DTC B0118/46 is recorded when a B+ short is detected in the side squib LH circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B0118/46	<ul style="list-style-type: none"> • Short in side squib LH circuit (to B+) • Side squib LH malfunction • Airbag sensor assembly malfunction 	<ul style="list-style-type: none"> • Side airbag assembly LH (Side squib LH) • Airbag sensor assembly • Floor No. 1 wire

HINT:


DTC B0118/46 is indicated only for the vehicle equipped with the side airbag.

WIRING DIAGRAM


See [page DI-432](#).

INSPECTION PROCEDURE

1	Prepare for inspection (See step 1 on page DI-432).
----------	--



2	Check floor No. 1 wire (side squib LH circuit).
----------	--



CHECK:

- Turn the ignition switch to ON.
- Measure the voltage between the body ground and SFL+ of the floor No. 1 wire connector on the side airbag assembly LH (side squib LH) side.


OK:

Voltage: Below 1 V

NG Repair or replace floor No. 1 wire.

OK

3 Check airbag sensor assembly.



PREPARATION:

- Turn the ignition switch to LOCK.
- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the connector to the airbag sensor assembly.
- Using a service wire, connect SFL+ and SFL- of the floor No. 1 wire connector on the side airbag assembly LH (side squib LH) side.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.

CHECK:

- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Clear the DTC stored in memory ([See page DI-432](#)).
- Turn the ignition switch to LOCK, and wait at least for 10 seconds.
- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Check the DTC ([See page DI-432](#)).

OK:

DTC B0 118/46 is not output.

HINT:

Codes other than code B0118/46 may be output at this time, but they are not relevant to this check.


NG

Replace airbag sensor assembly.

OK

4 Check side squib LH.

Side Squib LH





ON



DLC3

DTC B0118/46

H01018 AB0119
H10600 H01072

H13118

PREPARATION:

- Turn the ignition switch to LOCK.
- Disconnect the negative (–) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the side airbag assembly LH (side squib LH) connector.
- Connect the negative (–) terminal cable to the battery, and wait at least for 2 seconds.

CHECK:

- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Clear the DTC stored in memory ([See page DI-432](#)).
- Turn the ignition switch to LOCK, and wait at least for 10 seconds.
- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Check the DTC ([See page DI-432](#)).

OK:**DTC B0 118/46 is not output.****HINT:**

Codes other than code B0118/46 may be output at this time, but they are not relevant to this check.

NG

Replace side airbag assembly LH (side squib LH).

OK

From the results of the above inspection, the malfunctioning part can now be considered normal. To make sure of this, use the simulation method to check. If the malfunctioning part can not be detected by the simulation method, replace all SRS components including the wire harness.