

<b>DTC</b>	<b>B0133/62</b>	<b>Short in P/T Squib RH Circuit (to B+)</b>
------------	-----------------	--

## CIRCUIT DESCRIPTION

The P/T squib RH circuit consists of the airbag sensor assembly and the seat belt pretensioner RH.

It causes the SRS to deploy when the SRS deployment conditions are satisfied.

For details of the function of each component, see OPERATION on [page RS-3](#).

DTC B0133/62 is recorded when a B+ short is detected in the P/T squib RH circuit.


DTC No.	DTC Detecting Condition	Trouble Area
B0133/62	<ul style="list-style-type: none"><li>• Short in P/T squib RH circuit (to B+)</li><li>• P/T squib RH malfunction</li><li>• Airbag sensor assembly malfunction</li></ul>	<ul style="list-style-type: none"><li>• Seat belt pretensioner RH (P/T squib RH)</li><li>• Airbag sensor assembly</li><li>• Floor No. 2 wire</li><li>• Dash wire (Bench seat)</li></ul>

## WIRING DIAGRAM

See [page DI-539](#).

## INSPECTION PROCEDURE

<b>1</b>	<b>Prepare for inspection (See step 1 on <a href="#">page DI-764</a>).</b>
----------	--



<b>2</b>	<b>Check seat type.</b>
----------	-------------------------

### CHECK:


Confirm that the type of the front seat.

### OK:


**A: Separate seat**

**B: Bench seat**

<b>A</b>	<b>Go to step 6.</b>
----------	----------------------



### 3 Check floor No. 2 wire (P/T squib RH circuit).



#### **PREPARATION:**

Connect the negative ( - ) terminal cable to the battery, and wait at least for 2 seconds.

#### **CHECK:**

- Turn the ignition switch to ON.
- Measure the voltage between the body ground and PR+ of the floor No. 2 wire connector on the seat belt pretensioner RH (P/T squib RH) side.


#### **OK:**

**Voltage: Below 1 V**

**NG Repair or replace floor No. 2 wire.**

**OK**

## 4 Check airbag sensor assembly.



### PREPARATION:

- Connect the connector to the airbag sensor assembly.
- Using a service wire, connect PR+ and PR- of the floor No. 2 wire connector on the seat belt pretensioner RH (P/T squib RH) side.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.

### CHECK:

- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Clear the DTC stored in memory ([See page DI-432](#)).
- Turn the ignition switch to LOCK, and wait at least for 10 seconds.
- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Check the DTC ([See page DI-432](#)).

### OK:

**DTC B0 133/62 is not output.**

### HINT:


Codes other than code B0 133/62 may be output at this time, but they are not relevant to this check.

**NG**

**Replace airbag sensor assembly.**

**OK**

## 5 Check P/T squib RH.



### PREPARATION:

- Turn ignition switch to LOCK.
- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the seat belt pretensioner RH (P/T squib RH) connector.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.

### CHECK:

- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Clear the DTC stored in memory ([See page DI-432](#)).
- Turn the ignition switch to LOCK, and wait at least for 10 seconds.
- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Check the DTC ([See page DI-432](#)).

### OK:

**DTC B0 133/62 is not output.**

### HINT:

Codes other than code B0 133/62 may be output at this time, but they are not relevant to this check.


**NG**

**Replace seat belt pretensioner RH (P/T squib RH).**

**OK**

**From the results of the above inspection, the malfunctioning part can now be considered normal. To make sure of this, use the simulation method to check. If the malfunctioning part can not be detected by the simulation method, replace all SRS components including the wire harness.**

## 6 Check P/T squib RH circuit.



### PREPARATION:

Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.

### CHECK:

- Turn the ignition switch to ON.
- Measure the voltage between the body ground and PR+ of the seat belt pretensioner RH (P/T squib RH) side between the airbag sensor assembly and the seat belt pretensioner RH (P/T squib RH).

### OK:


**Voltage: Below 1 V**

NG

Go to step 9.

OK

## 7 Check airbag sensor assembly.



### PREPARATION:

- Turn the ignition switch to LOCK.
- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the connector to the airbag sensor assembly.
- Using a service wire, connect PR+ and PR- of the connector on the seat belt pretensioner RH (P/T squib RH) side between the seat belt pretensioner RH (P/T squib RH) and the airbag sensor assembly.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.

### CHECK:

- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Clear the DTC stored in memory ([See page DI-432](#)).
- Turn the ignition switch to LOCK, and wait at least for 10 seconds.
- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Check the DTC ([See page DI-432](#)).

### OK:

**DTC B0133/62 is not output.**

### HINT:


Codes other than code B0133/62 may be output at this time, but they are not relevant to this check.

**NG**

**Replace airbag sensor assembly.**

**OK**

# 8 Check P/T squib RH.



## PREPARATION:

- Turn the ignition switch to LOCK.
- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the seat belt pretensioner RH (P/T squib RH) connector.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.

## CHECK:

- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Clear the DTC stored in memory ([See page DI-432](#)).
- Turn the ignition switch to LOCK, and wait at least for 10 seconds.
- Turn the ignition switch to ON, and wait at least for 10 seconds.
- Check the DTC ([See page DI-432](#)).

## OK:

**DTC B0133/62 is not output.**

## HINT:

Codes other than code B0133/62 may be output at this time, but they are not relevant to this check.


**NG**

**Replace seat belt pretensioner RH (P/T squib RH).**

**OK**

From the results of the above inspection, the malfunctioning part can now be considered normal. To make sure of this, use the simulation method to check. If the malfunctioning part can not be detected by the simulation method, replace all SRS components including the wire harness.

# 9 Check floor No. 2 wire.



## PREPARATION:

- Turn the ignition switch to LOCK.
- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Disconnect the floor No. 2 wire from the dash wire.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.

## CHECK:

- Turn the ignition switch to ON.
- Measure the voltage between the body ground and PR+ of the floor No. 2 wire connector on the seat belt pretensioner RH (P/T squib RH) side.

## OK:

Voltage: Below 1 V

NG

Repair or replace floor No. 2 wire.

OK

Repair or replace dash wire.