

CIRCUIT INSPECTION


+B Power Source Circuit

CIRCUIT DESCRIPTION

This is the power source for motors such as the slide motor, reclining motor, front vertical motor and lifter motor.


WIRING DIAGRAM

LHD Models:



C


I25280

RHD Models:

I26268

INSPECTION PROCEDURE**1 Check LH SEAT fuse.****NG**

Check for short in all the harness and components connected to the LH SEAT fuse, and repair them .

OK**2 Check continuity between terminals GND, SGND of Power Seat Control ECU connector and body ground.****CHECK:**


Measure resistance between terminals GND, SGND of Power Seat Control ECU connector and body ground with connector being connected.

OK:

Resistance: Continuity (below 1 Ω)

NG

Repair or replace harness or connector.

OK**3 Check voltage between terminals +B of Power Seat Control ECU connector and body ground.****CHECK:**

Measure voltage between terminals +B of Power Seat Control ECU connector and body ground with connector being connected.

OK:

Voltage: 10 – 14 V

OK

Proceed to next circuit inspection shown on problem symptom table ([See page DI-786](#)).

NG

Repair or replace harness or connector.