

PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
Sliding roof control system does not operate.	1. Power Source Circuit 2. IG Switch Circuit 3. Sliding Roof Control Switch Circuit 4. Sliding Roof Control Gear Assembly with ECU	DI-968 DI-971 DI-973 IN-38
Sliding roof operates abnormally or stops half way.	1. Pulse Plate (Sliding Roof Limit Switch) Circuit	DI-975
Jam protection system does not operate.	1. Power Source Circuit 2. Sliding Roof Control Gear Assembly with ECU	DI-968 IN-38