

DIAR3-01


<b>DTC</b>	<b>26</b>	<b>Rear Inlet Air Temperature Sensor Circuit</b>
------------	-----------	--

## CIRCUIT DESCRIPTION

This sensor detects the rear inlet air temperature and sends the appropriate signals to the A/C amplifier.

DTC No.	Detection Item	Trouble Area
26	Open or short in rear inlet air temperature sensor circuit.	<ul style="list-style-type: none"> <li>• Rear inlet air temp. sensor</li> <li>• Harness or connector between rear inlet air temp. sensor and rear A/C amplifier</li> <li>• Rear A/C amplifier</li> </ul>


## WIRING DIAGRAM



108315

## INSPECTION PROCEDURE

1	<b>Check voltage between terminals TINR and SG of rear A/C amplifier connector.</b>
---	---

**PREPARATION:**

Remove rear A/C amplifier with connectors still connected.

**CHECK:**

- (a) Turn ignition switch to ON.
- (b) Measure voltage between terminals TINR and SG of rear A/C amplifier connector at each temperature.

**OK:**

**Voltage :**

**at 25° C (77° F) : 1.8 – 2.2 V**

**at 40° C (104° F) : 1.2 – 1.6 V**

**HINT:**


As the temperature increases, the voltage decreases.

**NG**

**Go to step 2.**

**OK**

**Proceed to next circuit inspection shown on problem symptoms table (See page DI-1238). However, if DTC 26 is display, check and replace rear A/C amplifier.**

**2 Check rear inlet air temperature sensor.****PREPARATION:**

Disconnect rear inlet air temperature sensor connector.

**CHECK:**

Measure resistance between terminals 1 and 2 of rear inlet air temperature sensor connector at each temperature.

**OK:****Resistance :**

at 25° C (77° F) : 1.65 – 1.75 k $\Omega$

at 50° C (122° F) : 0.55 – 0.65 k $\Omega$

**HINT:**

As the temperature increases, the resistance decreases.

**NG****Replace rear inlet air temperature sensor.****OK****3 Check harness and connector between rear inlet air temperature sensor and A/C amplifier (See page IN-38).****NG****Repair or replace harness or connector.****OK****Check and replace rear A/C amplifier.**