


DTC	42	Air Inlet Damper Control Servomotor Circuit
------------	-----------	--

CIRCUIT DESCRIPTION

The air inlet damper control servomotor is controlled by the A/C amplifier and moves the air inlet damper to the desired position.

DTC No.	Detection item	Trouble Area
42	Air inlet damper position sensor value does not change even if A/C amplifier operated air inlet damper control servomotor	<ul style="list-style-type: none"> • Air inlet damper control servomotor • Harness or connector between air inlet damper control servomotor and A/C amplifier • A/C Amplifier

WIRING DIAGRAM



C

I25726

INSPECTION PROCEDURE

1	Actuator check.
---	------------------------

PREPARATION:

- (a) Warm up the engine.
- (b) Set to actuator check mode ([See page DI-1226](#)).
- (c) Press the DEF switch and change it to step operation.

CHECK:


Press the DEF switch and check the operation of the air inlet damper and the condition of the blower.

OK:

Display Code	Air Inlet Damper
0 – 1	FRESH
2	R/F (50%)
3	RECIRC
4 – 7	FRESH


 OK

Proceed to next circuit inspection shown on problem symptoms table ([See page DI-1238](#)).

 NG

2 Check air inlet damper control servomotor.

LHD Models:



PREPARATION:

Remove the air inlet servomotor.

CHECK:

Connect positive (+) lead to terminal 5 and negative (-) lead to terminal 4.

OK:

The lever moves smoothly to REC position.


CHECK:

Connect positive (+) lead to terminal 4 and negative (-) lead to terminal 5.

OK:

The lever moves smoothly to FRS position.

RHD Models:



NG

Replace air inlet servomotor.

OK

3

Check harness and connector between air inlet damper control servomotor and A/C amplifier (See page IN-38).

NG

Repair or replace harness or connector.

OK

Check and replace A/C amplifier.