


Back Up Power Source Circuit

CIRCUIT DESCRIPTION

This is the back -up power source for the A/C amplifier. Power is supplied even when the ignition switch is off and is used for diagnostic trouble code memory, etc.

WIRING DIAGRAM




C

125715

INSPECTION PROCEDURE

1 Check voltage between terminal +B of A/C amplifier and body ground.

**PREPARATION:**

Remove the A/C amplifier with connector still connected.

CHECK:

Measure voltage between terminal +B of A/C amplifier connector and body ground.


OK:

Voltage : Battery positive voltage

OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-1238).

NG

2 Check ECU -B2 fuse.**PREPARATION:**

Remove ECU -B2 fuse from cowl side J/B RH.

CHECK:

Check continuity of ECU -B2 fuse.

OK:

Continuity

NG Check for short in all the harness and components connected to the ECU -B2 fuse (See attached wiring diagram).

OK

Check and repair harness and connector between A/C amplifier and battery.