

## REPLACEMENT

### REPLACEMENT REQUIREMENTS

In the following cases, replace the curtain shield airbag assembly or curtain shield airbag cover.

Case	Replacing part
If the curtain shield airbag has been deployed.	Curtain shield airbag assembly
If the curtain shield airbag assembly has been found to be faulty in trouble-shooting.	Curtain shield airbag assembly
If the curtain shield airbag assembly has been found to be faulty during checking items (See page RS-71).	Curtain shield airbag assembly
If the front pillar garnish has been found to be faulty during checking items (See page RS-71).	Front pillar garnish
If the roof headlining has been found to be faulty during checking items (See page RS-71).	Roof headlining
If the curtain shield airbag assembly has been dropped.	Curtain shield airbag assembly

### CAUTION:

For removal and installation of the curtain shield airbag assembly, see page RS-70 and RS-79. Be sure to follow the correct procedure.