

## REPLACEMENT

### REPLACEMENT REQUIREMENTS

In the following cases, replace the airbag sensor assembly.

- If the SRS has been deployed in a collision.
- If the airbag sensor assembly has been found to be faulty in troubleshooting.
- If the airbag sensor assembly has been dropped.

### CAUTION:

**For removal and installation of the airbag sensor assembly, [see page RS-81](#) and [RS-84](#). Be sure to follow the correct procedure.**