

## INSTALLATION

### 1. INSTALL NO.2 ROOF DRIP SIDE FINISH MOULDING CLIP

If the No.2 roof drip side finish moulding clip comes off.

- (a) Using a heat light, heat the body mounting surface to 40 – 60 °C (104 – 140 °F).

#### NOTICE:

**Do not heat the body excessively.**

- (b) Remove the adhesive tape and adhesive from the body.
- (c) Wipe off stains with cleaner.
- (d) Using a heat light, heat the body and moulding clip.

**Body: 40 – 60 °C (104 – 140 °F)**

**Moulding: 20 – 30 °C (68 – 86 °F)**

#### NOTICE:

**Do not heat the body and moulding excessively.**

- (e) Install the clip.

### 2. INSTALL ROOF DRIP SIDE FINISH MOULDING

#### 3. w/o Roof Rail, Roof Rack:

**INSTALL NO.2 ROOF DRIP SIDE FINISH CENTER MOULDING**

#### 4. w/ Roof Rail:

**INSTALL ROOF RAIL (See page BO-227)**

#### 5. w/ Roof Rack:

**INSTALL ROOF RACK (See page BO-228)**