


ROOF PANEL (ASSY): Normal Roof


REMOVAL








INSTALLATION





 Before temporarily installing the new parts, apply body sealer to the windshield header panel, roof panel reinforcement and back door opening upper frame.

HINT:

- Apply just enough sealer for the new parts to make contact.
- 2) For other sealing points, refer to Section AR.
- 2. After installing the new parts, apply foamed materials.