


ROOF PANEL (ASSY): Moon Roof


REMOVAL







[If reusing the roof panel reinforcement]






INSTALLATION







 Before temporarily installing the new parts, apply body sealer to the windshield header panel, roof panel reinforcement and back window frame.

HINT:

- Apply just enough sealer for the new parts to make contact.
- 2) For other sealing points, refer to Section AR.
- 2. Bend the flange hem with a wooden hammer and dolly.

HINT: Perform hemming three steps, being careful not to warp the panel.

3. After installing the new parts, apply foamed materials.