□ : Location of Connector Joining Wire Harness and Wire Harness

[LHD: w/o Seat ECU]

