


2. Layout of Main Components



*1: For Automatic Transaxle model

*2: For Manual Transaxle model

258LC02

► Function of Main Components ◀

Item	Function
Television Camera	<ul style="list-style-type: none"> Mounted on the back door to transmit the rearview image of the vehicle to the Television Camera ECU. A color video camera that uses a CCD (Charge Coupled Device) and a wide-angle lens.
Television Camera ECU	<ul style="list-style-type: none"> Transmits video signals, which contain a composite of the rear view of the vehicle taken with the television camera and the warning message, to the multi display. Television camera ECU effects control of the system by receiving the signal from the Neutral Start Switch (or Back-Up Light Switch).
Multi Display	Receives video signals containing a composite of the rear view of the vehicle and the warning message from the television camera ECU, and displays on the multi display.
Neutral Start Switch (AT)	Transmits a reverse shift position signal to the Television camera ECU.
Back-Up Light Switch (MT)	