

3. Operation

1) General


- With the ignition switch ON, if the driver shifts the shift lever to reverse, the display of the multi display switches to operate this system. In this state, if the driver moves the shift lever to a position other than reverse, or switches the modes on the multi display, the rear view display stops and switches to the display of another mode.

CAUTION

- Never depend on the rear view monitor system entirely when backing up. Always make sure your intended path is clear. Use caution, just as you would when backing up any vehicle.
- Never back up while looking only at the screen. The image on the screen is different from actual conditions. Depicted distances between objects and flat surfaces will differ from actual distance. If you back up while looking only at the screen, you may hit a vehicle, a person or an object. When backing up, be sure to check visually behind and all around the vehicle, both directly and with mirrors, before proceeding.

2) Area Displayed on Screen

- On the Multi Display, objects on the right of the vehicle appear on the right side of the display panel, and objects on the left of the vehicle appear on the left side of the display panel.
- The television camera uses a wide-angle lens. The perceived distance from the image that appears on the screen differs from the actual distance.



NOTE: Area displayed on screen may vary according to vehicle status or road conditions.

The area detected by the television camera is limited. The television camera does not detect objects close to either corner of the bumper or under bumper.