
AUTOMATIC TRANSMISSION (A750F for 1HD -FTE) HOW TO PROCEED WITH TROUBLESHOOTING

DIAV7-02



When using hand-held tester, troubleshoot in accordance with the procedure on the following pages.

