

<b>DTC</b>	<b>P0605/17</b>	<b>Interior IC Malfunction</b>
------------	-----------------	--------------------------------

<b>DTC</b>	<b>P1633/89</b>	<b>Interior IC Malfunction</b>
------------	-----------------	--------------------------------

## CIRCUIT DESCRIPTION

DTC No.	DTC Detection Condition	Trouble Area
P0605/17 P1633/89	ECU malfunction	• Engine ECU

## INSPECTION PROCEDURE

### HINT:

Read freeze frame data using the intelligent tester II. Freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, and other data from the time the malfunction occurred.

**Replace engine ECU.**